
KURODA

BALLSCREW ACTUATORS

A ballscrew actuator of KURODA is a compact single-axis unit consisting of a ball screw and a slide guide. With its slide block set in U-guide rail, the actuator has achieved low-profile design and compact shape, making it possible to considerably reduce necessary space as compared with the usual table type structure. Despite of its compact structure, the actuator with U-guide rail shows high rigidity against bending moment and deflection, and it can be applied to a structure supported by one end. The linear motion unit, which is gothic arched and in 4 points-contact structure, makes it possible to deliver high precision and high rigidity.

POSITIONS OF BALLSCREW ACTUATORS



WIDE VARIATIONS

Made				SG s	series				SE s	eries		SC series (Note 2)		
Mode	HINO.	SG20	SG26	SG33	SG3320	SG46	SG55	SE15	SE23	SE30	SE45	SC23	SC30	SC45
Perforn grade (P: Repeated positioning accuracy $\pm 1 \ \mu$ m H: Repeated positioning accuracy $\pm 3 \ \mu$ m						H: Repeated positioning accuracy $\pm 3 \mu$ m (Note 3) U: Repeated positioning accuracy $\pm 5 \mu$ m W: Repeated positioning accuracy $\pm 10 \mu$ m						lote 3)
Screw shat	t dia. (mm)	6	8	10	12	15	20	6	8	10	15	8	10	15
	1	\bigcirc						\bigcirc						
	2		O					\bigcirc	\bigcirc			\bigcirc		
Land	4									\bigcirc			\bigcirc	
Lead (mm)	5	\bigcirc	\bigcirc	\bigcirc					\bigcirc	\bigcirc	\bigcirc	\bigcirc	\bigcirc	0
	8													
	10			O		O				\bigcirc	O		O	0
	20				O	O	O				O			\bigcirc

 \bigcirc : In-stock items \bigcirc : Manufactured by order

(Note 1) The above table shows precision information on repeated positioning accuracy in particular, as an example.

Performance of actuators may be different from the values shown above, depending on applied options and usage. For other precision information, refer to description pages for each series.

(Note 2) SC series is a full-cover version of SE series ballscrew actuators.

For more information, refer to front matter 5, pages 6 and 89 to 105.


(Note 3) Performance grade H is manufactured by order.



FEATURES OF SG/SE SERIES

No necessity for adjustment

Ball screw and slide guide are integrated in ballscrew actuator, eliminating the need for complicated fine adjustment and reducing the number of working processes to a great extent.





High rigidity

With U-guide rail, rigidity of ballscrew actuator has remarkably improved despite of its compact structure, making it possible to be applied even to a structure supported at only one end.

High accuracy

Linear motion unit uses "4 or 2 Ballway of 4 points-contact" structure to assure high rigidity. Guide rail, slide block and ball screw shaft are precisely worked, making accurate positioning possible.







Gothic arch shape 4 points-contact structure

Space-saving

With its slide block set in U-guide rail, the actuator has achieved low-profile design and compact shape, making it possible to considerably reduce necessary space as compared with usual table type structure.






(Unit: mm)




KEY COMPONENTS AND MATERIALS OF SG AND SE SERIES



No.	Part name	Material	Remarks
1	Motor bracket	Aluminum alloy	Anodized treatment or baking finish
2	Coupling cover	Aluminum alloy	Anodized treatment
3	Guide rail	Stainless steel (SG20, SG26) Carbon steel (SG33, SG46, SG55, SE15, SE23, SE30, SE45)	Black coating (Note 1)
4	Dust cover	Aluminum alloy	Anodized treatment
5	Ball screw shaft	Chromium-molybdenum steel (SG series) Carbon steel (SE series)	
6	Slide block	Chromium-molybdenum steel	
\bigcirc	Housing	Aluminum alloy	Anodized treatment or baking finish
8	Grease nipple	Stainless steel	
9	Damper (Note 2)	Synthetic rubber	
10	Dustproof cover	Aluminum alloy	Anodized treatment
1	Sub-table	Aluminum alloy	Anodized treatment
12	Intermediate flange	Aluminum alloy (SG20, SG26, SE15, SE23, SE30, SE45) Carbon steel (SG33, SG46, SG55)	Anodized treatment Black coating

(Note 1) Guide rails made from stainless steel are not surface-treated.

(Note 2) Damper position of SG series is different from SE series. For more information, refer to dimensions of each series. (Note 3) Stainless steel is used for bolts and machine screws to joint components of actuator.




No.	Part name	Material	Remarks
1	Motor mounting plate	Rolled steel	Black coating
2	Tension plate	Stainless steel	
3	Pulley cover	Stainless steel (SG series) Cold-rolled steel plate (SE/SC series)	Anti corrosive black coating (Note 4)
4	Timing belt	Resin	
(5)	Timing pulley	Aluminum alloy	
6	Tension bolt	Stainless steel	

(Note 4) Anti corrosive black coating of pulley cover applies to SE and SC series.




FEATURES OF SC SERIES (FULL-COVER TYPE)

Full-cover type SC series, built on KURODA SE series, has remarkably improved its dust-preventive performance.



Remarkably improved dust prevention!

Compared to SE series with dustproof cover, dust prevention has been remarkably improved through making clearance on side face of actuator as narrow as it can be and effectively applying new center sheet designed to straddle the tables, so as to prevent entry of dust.



Down-sized body meeting space-saving needs!

SC series has full-cover type body with the same width and dimensions as SE series' guide rail. Replacing SE series with the full-cover type SC series requires just the same mounting space (width) as SE series (Note that mounting height is different).

Easy maintenance!

In order for more efficient grease-up work, which is usually found cumbersome, a central grease filler hole is provided on the side face of the table, as standard equipment of SC series.

Supplying grease to ball screws and guide parts can be completed at a time through the central grease filler hole. (A plug is equipped with standard spec. model).


Grease nipple to be attached to grease filler hole is available as an option. (For more information, refer to pages 96, 100, and 104.)

Guide with remarkable rigidity!

Having steel U-guide rails similar to SG/SE series, SC series shows high rigidity despite of its compact structure, and it can be applied to a structure supported by one end. (For more information, refer to front matter 11.)



KEY COMPONENTS AND MATERIALS OF SC SERIES



No.	Part name	Material	Remarks
1	Motor bracket	Aluminum alloy	Anodized treatment
2	Coupling cover	Aluminum alloy	Anodized treatment
3	Guide rail	Carbon steel	Black coating
4	Side cover	Aluminum alloy	Anodized treatment
5	Table	Aluminum alloy	Anodized treatment
6	Table cover	Synthetic resin	
\bigcirc	Center sheet	Stainless steel	
8	Housing	Aluminum alloy	Anodized treatment


(Note 1) Ball screws used for SC series have the same specifications as SE series.

(Note 2) Stainless steel is used for bolts and screws to joint components of actuator.



VARIATIONS OF SLIDE BLOCK

Two types of actuator with long block and short block are available. Additional types with either 2 long blocks or 2 short blocks are also available. Appropriate type can be selected from the variations according to your purpose of use.





Front matter

SUMMARY OF ACCURACY INDICATORS


Performance of ballscrew actuators are shown using various accuracy indicators described below. For details in tolerance of the accuracy indicators, refer to table of performance (accuracy) information for each series.

Repeated positioning accuracy

Repeat positioning of slide block in the same direction 7 times, measure stop position of slide block and halve maximum difference between obtained readings. Perform this measurement at the center and both ends of travel distance. Maximum value among obtained value is used as measured value.

Repeated positioning accuracy

 $=\pm 1/2$ ((maximum value of ln) - (minimum value of ln))




Positioning accuracy


Position slide block properly in a fixed direction and use the obtained position as datum point. Perform positioning of slide block in the same direction and measure difference between actual traveling distance of slide block from datum point and distance ordered to be traveled from datum point. Perform this measurement throughout stroke range and use maximum value.

Positioning accuracy=($\Delta \ Qn$) max

Traveling parallelism B

Fix indicator at the center of slide block and apply it to surface plate equipped with guide rail. Move slide block throughout traveling distance and use maximum distance among readings of test indicator as measured value.





Backlash


Move slide block by rotating ball screw shaft and read test indicator when slide block is slightly moved and use its reading as reference value. Move slide block from this state in the same direction by pressuring prescribed load and measure difference between reading of test indicator with load removed and reference value. Perform this measurement at the center and both ends of traveling distance and use maximum value as a measured value.

 $Backlash = \Delta Q$

\triangle

• Firmly tighten the fixed part and connection of the ballscrew actuator.

Improper mounting of the body may adversely affect safety and accuracy depends on the circumstances.






REFERENCE DATA ON ACCURACY ACCURACY OF UNIT PRODUCT

Lost Motion


Perform positioning in a positive (or negative) direction and measure the position (Q_1) . Move the slide block in the same direction and perform positioning in a negative (or positive) direction and measure the position (Q_1) . Move it further in the same direction and thereafter repeat the procedure in the positive and negative directions seven times each. Obtain the differences of the average values of the stop positions. Conduct this measurement for the entire moving range and use the obtained maximum value as a measured value.



Traveling Parallelism A


In the case of ballscrew actuators:

Set dial gauge on surface plate, fix indicator on top of slide block, obtain the maximum difference of dial gauge readings in measurable moving range in longitudinal direction of slide block. And use it as a measured value. Since the measurable range is small for ballscrew actuators, Traveling Parallelism B is used as the measurement method for all of the cases except for a few exceptions.



In the case of X-Y stages:

Set dial gauge on surface plate, fix indicator at the center of table, obtain the maximum difference of dial gauge readings in entire moving range in X-Y direction. The maximum difference is used as a measured value.






REFERENCE DATA ON ACCURACY ACCURACY OF UNIT PRODUCT

Squareness

In case squareness cannot be measured on the table top: Set a dial gauge on the table top. On surface plate close to the table travel range, fix a square gauge in parallel to X (or Y) travel direction.


Place a fix indicator against the side of square gauge parallel to Y (or X) travel direction. The maximum reading value of the dial gauge in the entire travel range is a measured value of squareness.



In case squareness can be measured on the table top:

Set a dial gauge on surface plate. On the table top, fix a square gauge in parallel to X (or Y) travel direction.


Place a fix indicator against the side of square gauge parallel to Y (or X) travel direction. The maximum reading value of the dial gauge in the entire travel range is a measured value of squareness.






RIGIDITY

Linear motion units of SG, SE, and SC series, having gothic-arched grooves and 4 points-contact structure on guide rails and slide blocks, have attained high rigidity. Displacement by each radial load in each size with long block configuration is shown below as a reference.






Gothic arch shape 4 points-contact structure

Displacement of Slide block by Radial Load

SG series




SE/SC series

Sectional Secondary Moment of Guide Rail

The following table shows sectional secondary moments of guide rails in each size.

	Sectional seconda	ary moments (mm ⁴)	Maaa
Model No.	Ix (X axis)	ا ب (Y axis)	Mass (kg/100mm)
SG20	6.50×10 ³	6.00×10 ⁴	0.250
SG26	1.69×10⁴	1.47×10 ⁵	0.380
SG33	5.11×10⁴	3.42×10⁵	0.600
SG46	2.42×10⁵	1.49×10 ⁶	1.240
SG55	2.29×10⁵	2.28×10 ⁶	1.500
SE15	2.71×10 ³	2.36×10 ⁴	0.147
SE23, SC23	1.44×10 ⁴	1.37×10⁵	0.410
SE30, SC30	3.88×10 ⁴	3.14×10⁵	0.560
SE45, SC45	1.45×10⁵	1.26×10 ⁶	1.110





OPTION AND MANUFACTURING BY ORDER

Cotogony				S	G series	1			SE se	ries		S	C series	;
Category		Item	SG20	SG26	SG33	SG46	SG55	SE15	SE23	SE30	SE45	SC23	SC30	SC45
	Motor Intermediate flange		0	0	0	0	0	0	0	0	0	0	0	0
	bracket configu-	R0/RN type bracket (Note 1)	0	0	0	0	0	—	—	0	0	—	0	0
	ration	Parallel motor mounting unit	—		0	0				0	0		0	0
		Dustproof cover	0	0	0	0	0	0	\bigcirc	0	0		—	
	Type of	Standard full-cover (Note 2)	—		—							0	0	0
	cover	Full-cover with grease nipple (Note 2)										0	0	0
0000		Full-cover with wiper (Note 2)	_									0	0	0
Option		Full-cover with grease nipple and wiper (Note 2)	—		—							0	0	0
	Sensor	Photo-microsensor Ass'y	0	0	0	0	0		0	0	0	0	0	0
	0011001	Proximity sensor Ass'y	0	0	0	0	0	0	0	0	0	0	0	0
	Sensor rail Ass'y			0	0	0	0	0	0	0	0	0	0	0
	Surface t	Surface treatment (Note 3)			0	0	0	0	\bigcirc	0	0	0	0	0
	Dust prev	Dust preventive grease			0	0	0	0	0	0	0	0	0	0
	Dowel pi	Dowel pin hole (slide block)			0	0	0		0	0	0			—
	Dowel pi	n hole (guide rail)	0	0	0	0	0		0	0	0	0	0	0
	Intermed	iate stroke												
	Oil hole (Note 4)										—	—	—
	XY brack	et												
Manufactured	Motor as	sembling												
by order (Note 8)	Long rail	configuration												
(1000 0)	Grease o	ptions (Note 5)												
	Motor bra	acket configuration (Note 6)												
	Sensor o	Sensor options (Note 7)												

○: Option —: Not available ●: Manufactured by order

(Note 1) R0 type bracket is applied to SG series and RN type is applied to SE and SC series.

(Note 2) Full-cover type with wiper and with grease nipple is applied only to SC series.

(Note 3) Anti corrosive black coating (film thickness 1-2 $\mu\,m)$ is provided as surface treatment.

(Note 4) Oil hole for SG and SE series is applied to the configuration with sub-table.

(Note 5) Any grease application other than standard or option grease applications will be provided on a manufactured by order basis.

(Note 7) Ballscrew actuator requiring a sensor other than option configuration or two sensors attached on both ends will be provided on a manufactured by order basis.

(Note 8) For ballscrew actuators to be provided on a manufactured by order basis, specifications will be determined after consultation with customers. Please consult KURODA after completing the Specification Data Sheet attached at the end of this catalog.



⁽Note 6) Ballscrew actuator with motor bracket or intermediate flange configuration other than standard or option configuration will be provided on a manufactured by order basis.

HOW TO INTERPRET MODEL NO.

Model N	No. Lead	Slide block	Guide rail length	Performance grade		Motor bracket configuration	Type of cover	Sensor]	Surface treatment	Grease		Dowel pin hole
SG3	3 10	А	- 500	Р	_	A1	С	С	-	Ν	Ν	-	PS
1	2	3	4	5		6	0	8		9	10	-	0

Model No. of Main Body

Model No. of Option

1 Model of ballscrew actuator

The 2-digits number represents height of mounting surface, from the bottom face of guide rail to top face of slide block. (For SG/SE series with dustproof cover and SC series, Model No. of the unit used as base of the body is shown.)

SG series	SG20	SG26	SG33	SG46	SG55
SE/SC series	SE15	SE/SC23	SE/SC30	SE/SC45	

2 Lead of ball screw

Permissible speed varies depending on the lead. For more information, refer to dimensions of each series.

Land			SG series			SE/SC series						
Lead	SG20	SG26	SG33	SG46	SG55	SE15	SE/SC23	SE/SC30	SE/SC45			
1mm	0					0						
2mm		0				0	0					
4mm								0				
5mm	0	0	0				0	0	0			
10mm			0	0				0	0			
20mm			0	0	0				0			

③ Variation of slide blocks and number of blocks to be mounted

For configuration with 2 slide blocks, a driving block and driven block in combination is mounted. For more information, refer to dimensions of each series.

④ Guide rail length

For more information, refer to dimensions of each series. Please note that the guide rail length is different from overall length or maximum stroke length of actuator.

Model No.				S	Standard gu	ide rail leng	th			
SE15	100	150	200							
SE23	150	200	250	300						
SE30	150	200	300	400	500	600	700	750		
SE45	340	440	540	640	740	840	940			
SC23	150	200	250	300						
SC30	150	200	300	400	500	600	700	750		
SC45	540	640	740	840	940					
SG20	100	150	200							
SG26	150	200	250	300						
SG33	150	200	300	400	500	600*				
SG46	340	440	540	640	740	840*	940*	1040*	1140*	1240*
SG55	980	1080	1180	1280*	1380*					

 $\boldsymbol{\cdot}$ Asterisked (*) item in the above table applies only to performance grade H.

· For long rail configurations, please consult KURODA.

(5) Performance of ballscrew actuators, including various positioning accuracy indicators and traveling parallelism For more information on accuracy, refer to a table of accuracy information for each series.

6 Motor bracket configuration

Intermediate flange may be used in combination with basic configuration. For more information, refer to a table of motor bracket configurations and motor option for each series.

⑦ Type of cover

For more information, refer to dimensions of each series.

8 With or without sensor / type of sensor

For more information, refer to dimensions of each series.

(9) With or without surface treatment applied on guide rails and ball screws

With standard specifications (Symbol N), only guide rails are treated with black coating (except for guide rails made from stainless steel).

 ${\scriptstyle \textcircled{10}}$ Type of grease applied on slide blocks and ball screws of ballscrew actuators

With standard specifications, Multemp PS No.2 Grease (KYODO YUSHI CO., LTD.) is contained.

① Dowel pin holes on guide rails and slide blocks The column will be left blank (no symbol) if actuator is without dowel pin holes. For more information, refer to configuration drawings for each series.






FOR SAFETY USE

Be sure to read the following instructions before use. For common instructions, refer to the text of this catalog.

The following safety precautions recommend the correct usage of our products to prevent an injury and a damage. These precautions are classified into 3 categories : "DANGER", "WARNING" and "CAUTION" according to the degree of possible

injury or damage and the degree of impendence of such injury or damage.

Be sure to follow all these precautions, as they include important contents regarding safety.



Be sure to obey "Labor Safety and Sanitation Law" and other safety rules and regulations in addition to these precautions. There is some situation that may lead to a serious result according to circumstances, even if it is mentioned in the category of "CAUTION". Be sure to follow these precautions, as they contain important matters.



• Select a ballscrew actuator properly.

As operating conditions for products mentioned in this catalog are diversified, the applicability of ballscrew actuator to the intended system should be determined by the total system designer or the person who determined specifications for such system after conducting an analysis and testing as necessary.

The person who determined the applicability of the system shall be responsible for assuring the intended system performance and safety. When configuring a system, the system designer should thoroughly examine all specifications for such a system by referring to the latest product catalog and data, and also take into consideration the possibility of equipment troubles.

- The ballscrew actuator should be handled by persons who have sufficient knowledge and rich experience. Thoroughly read this catalog and operation manual before use.
 - Never disassemble the ballscrew actuator. Dust can enter the inside, degrading the accuracy of the module and causing an accident. When the ballscrew actuator has been disassembled from necessity, return it to our company for repair and reassembling. (In this case, repairing charges are required.)
 - · When mounting a ballscrew actuator to a machine and dismounting it from machine, check that a fall prevention means has been taken and the moving part of the machine has been fixed beforehand.
- When using the ballscrew actuator in the following conditions or environments, take the proper safety measures and consult KURODA beforehand.
 - \cdot Conditions and environments other than specified and outdoor use.
 - · Applications to nuclear power equipment, railroads aircraft, vehicles, medical equipment, equipment connected with food and drink, and the likes.
 - \cdot Applications which require extreme safety and will also greatly affect men and property.
- During operation, make sure to keep your hands away from either of stroke ends, where slide block moves, to prevent your finger from being caught.
- During operation, make sure to keep your hands away from screws and axis terminals of ball screw shaft, which are rotating parts, to prevent your hands from being caught.
- Pay adequate attention not to allow the actuators to be used for military purpose including for arms and weapons.





BALLSCREW ACTUATOR/COMMON INSTRUCTIONS

Be sure to read the following instructions before use. Also refer to "FOR SAFETY USE".

DESIGN

\land WARNING

• Especially when there is the possibility that the ballscrew actuator is dangerous to the human body, provide it with a protective cover.

When there is the possibility that the load and the moving part of the ballscrew actuator are dangerous to the human body, design the structure to prevent the human body from touching such load and moving part directly.

- Firmly tighten the fixed part and connection of the ballscrew actuator.Improper mounting of the body may adversely affect safety and accuracy according to circumstances.
- Take into consideration the behavior of the ballscrew actuator in an emergency.

When the machine is immediately stopped in an emergency by a person or by a safety device in case of power failure or system trouble, the motion of the module can injure the human body and can damage the machine. So design the machine to prevent an injury to the human body and a damage to the machine.

SELECTION

🕂 WARNING

• Check specifications.

Be sure to use the ballscrew actuator within the given specifications.

• When selecting a rigid type as coupling for connecting a motor, consult KURODA.

MOUNTING

\land CAUTION

• Be careful not to dent and flow the body and the mounting surface of the table, side cover, and center sheet.

Such dent or flaw will degrade parallelism of mounting surface, resulting in rattling of the guide and increased slide resistance. Note that, since the center sheet of SC series are very thin, such dent or flaw may ruin its dust preventive capability or lead to damage of the sheet function.

- When connecting the ballscrew actuator to a load with an external support or guide, do so in accordance with a proper connecting method and perform centering satisfactorily.
- When mounting a load, do not apply an excessive shock or moment.

If the ballscrew actuator receives external force exceeding the permissible moment, the guide will loosen and sliding resistance will increase.

• Do not start the system until it is confirmed that the ballscrew actuator works properly.

After mounting the ballscrew actuator, perform an appropriate functional test and make sure that it is correctly mounted and works safely without fail before starting the system.

 Although corners of components, such as motor bracket, housing, side cover, and center sheet, are beveled, pay enough attention not to hurt yourself when handling them.

OPERATING ENVIRONMENT

🕂 Danger

• Do not use the ballscrew actuator in a place where an explosive atmosphere exists.

\land WARNING

- Do not use the ballscrew actuator in an atmosphere containing corrosive gases, chemicals, seawater, water and vapor and in a place where it can be stained with such matters.
- When using the ballscrew actuator in a place where it is exposed to dust, cuttings, spatters, etc., fit a protective cover or other protector.
- Do not use the ballscrew actuator in a vibratory or shockable place ; otherwise causing a bad condition or breakdown.

When using the ballscrew actuator in such an environment, consult KURODA.

▲ CAUTION

 Since the SC series is equipped with sheet magnet on side covers for attracting center sheet to keep its position, be careful not to have the magnet contaminated with iron power or metallic fragments.

LUBRICANTS

▲ CAUTION

- Unless otherwise specified, the nut contains Multemp PS No.2 Grease (KYODO YUSHI CO., LTD.) as a lubricant.
- Checking and supplying lubricant

Check the lubricant 2 to 3 months after the ball screw is used for the first time. If it is extremely dirty, wipe off old grease and apply new grease. Then, check and supply the lubricant once every year as a general rule. However, as the service life of lubricants varies according to operating conditions and environment, adjust the intervals properly.

When feeding additional grease (lubricant), use the same brand of grease as initially contained.

With SC series, a central grease filler hole (M3) is provided on side surface of table, making it possible for the grease to be supplied to ball screw and guide through the filler hole.

Supply additional grease as necessary, preferably with the interval indicated above. When adding grease, 2 dispenses by grease gun (approx. 1 to 2 cc) should be supplied.

After supplying additional grease, operate the table to the extent of full stroke to apply the grease over the component. Wipe off excess grease attached around the central grease filler hole.

• Do not use at high temperature over 60 celsius degree.

As resin is used in ballscrew actuator, use at lower temperature than 60 celsius degree. For ballscrew actuator with sensor, use at lower temperature than 55 celsius degree.



VARIATIONS

Mode	el No.	SE15	SE23	SE30	SE45
Perforn gra		U: Repeated	d positioning a	accuracy ±3µ accuracy ±5µ accuracy ±1	um (Note 2)
Screw shat	ft dia. (mm)	6	8	10	15
	1	O			
	2	O	0		
Lood	4			O	
Lead	5		0	0	0
(mm)	8				
	10			O	O
	20				Ô



©: In-stock items ●: Manufactured by order

(Note 1) Performance grade H is manufactured by order.

(Note 2) Performance may be different from the values shown above, depending on usage.

HOW TO INTERPRET MODEL NO.

SE30	05	Α -	150		U -	A1	N	N	-	Ν	N	- [PS
1	2	3	4	(5	6	7	8		9	10		(1)
① Mode	l ② Lead			⑤ Perfo	ormance	grade			⑨ Su	Surface treatment (Note 3)			
① Mode	el ② Lead]		Н	Repeate	d positionir	ng accuracy	±3μm	N	S	Standard treatment		
SE15	1,2]		U	Repeate	d positionir	ng accuracy	±5µm	L	A	Anti corrosive black coat		
SE23	2, 5			W	Repeated	d positionin	g accuracy:	±10μm			(Al-4- 4)		
SE30	4, 5, 10			6 Moto	r bracket	t configura	ation		10 Gre	ease	(Note 4)		
SE45	5, 10, 20			~						el	Greas	е	
	block			Model			onfiguration	n	SE15	- NI	: Standard (Troop	
③ Slide			-	SE15	AO, A1,	,			SE23	2 5	: Dust preve	-	
Model	Slide b	lock	_	SE23		A2, A3, A5		1	SE30)	KURODA		
SE15	A: With 1 long	block		SE30	AU, AT, RN, E		I, A5, A7, B	1,	SE45	5			
	B: With 2 long		SE45	A0, A1,	① Do	wel	pin hole 🛯	te 5)					
	A: With 1 long					, u			Blank	< N	lo dowel pin	hole	•
	B: With 2 long			⑦ Туре	of cover				PS	F	or slide bloo	ck on	ly
	C: With 1 shore D: With 2 shore			N	Without	cover			PR	F	or guide rail	only	,
		I DIOCKS		С	With co	ver			PSR		or both slide	e bloo	ck and
④ Guide	e rail length (Not	e 1) (Note 2)	_	8 Sens	or				1 011	g	uide rail		
Model	Guide rail leng	gth (mm)		Model		Sens	or						
SE15	100, 150, 200)			N: With	out sensor	-						
	150, 200, 250	,		SE15	K, E: Proximity sensor								
	150, 200, 300 600, 700*, 75				1: For sensor rails only N: Without sensor								
	240 440 540 640 740				S:Photo-microsensor K, E: Proximity sensor 1: For sensor rails only								
					1.1013		only						

(Note 1) For specifications of guide rail with long rails or intermediate stroke with non-standard length, consult KURODA. (Note 2) The marked "*" values in the table are applied to performance grade U and W.

1: For sensor rails only

M, Y, C, P: Photo-microsensor K, E: Proximity sensor

N: Without sensor

(Note 3) With standard specifications of surface treatment (Symbol: N), only guide rails are treated with black coating.
 (Note 4) With standard grease (Symbol: N), Multemp PS No.2 Grease (KYODO YUSHI CO., LTD.) is contained in slide block and ball screw components.

(Note 5) Dowel pin hole configuration is not available for SE15.

(Note 6) With Lubrication unit LUBSEAL specifications refer page from 118 to 119.

SE30


SE45




SPECIFICATIONS

	M	odel No.			SE	1501	SE15	502	SE2	302	SE2	305	SE30	04	SE3005	SE3010	SE4505	SE4510	SE4520
	Perform	mance grad	е		W	UH	WU	Н	wι	JН	wι	JH	WU	Н	WUH	WUH	WUH	W U H	WUH
	Rad	ial clearanc	e	μm		-3	3~0			-3	3~0				-3~0			$-5 \sim 0$	
		Basic dynamic load rating	С	kN		1	.6			4	1.3				7			27	
		Basic static load rating	Co	kN		2	.7			7	7.0				11.8			45.0	
			MP			1	0			2	46				101			572	
	Long	01.01	M_{2P}			6	60			2	76				606			3,432	
	block	Static permissible	M _Y	N∙m		1	1			5	51				120			681	
		moment	M_{2Y}			7	'1			3	06				720			4,086	
			M_{R}			2	28			1	34				260			1,410	
Guide			M_{2R}			5	56			2	68				520			2,820	
Guide		Basic dynamic load rating	С	kΝ														16.9	
		Basic static load rating	Co	kN														28.1	
			M_P															223	
	Short	Otatia	M_{2P}		ĸ	lot av	ailabl	Δ	Not available			N	ot availab		1,341				
	block	Static permissible	$M_{\rm Y}$	N∙m		voi av	anabi	0		Jiav	anac			1.11	or availat	ne -		266	
		moment	M_{2Y}															1,598	
			M_{R}															887	
			M_{2R}															1,774	
	Sh	aft diameter	r	mm		(6			1	8				10			15	
Ball		Lead		mm		1	2		2	2		5	4		5	10	5	10	20
screw	Basic dy	namic load rating	Ca	kN	0	.39	0.5	4	1.	.8	1	.9	3.0)	3.0	2.0	5.1	5.1	3.1
	Basic st	atic load rating	Coa	kΝ	0	.77	0.7	6	3	.2	3	.1	5.3	}	5.3	3.2	10.5	10.5	6.6
Fixed	Mo	del No. of b	earir	ng	604	1 or e	quival	ent	AC6-1	16DF (or equi	/alent	708	DF	P5 or equ	uivalent	5201	A or equiv	/alent
side	Basic dy	namic load rating	Cb	kN		C).5			1	.79				4.40		5.90		
bearing	Basic st	atic load rating	Cob	kΝ		0	.19			1	.76				4.36		3.20		

DIRECTION OF MOMENT







ACCURACY

	Guide rail length	Repeated	positioning (μm)	accuracy	Positic	ning ac (μm)	curacy	Travelli	ng paral (μm)	lelism B	E	acklas (µm)	h		rting tor (N • m)	•
No.	(mm)	W	U	Н	W	U	Н	W	U	н	W	U	Н	W	U	Н
	100				6	5										
SE15	150	±10	± 5	±3	7	0	60	1	5	15	20	5	5	0.010	0.012	0.012
	200				7	5										
	150				7	0										
SE23	200	±10	±5	±3	7	5	60	1	5	15	20	5	5	0.03	0.06	0.06
3623	250	- 10	-5		8	5	00	1	5	15	20	Э	5	0.03	0.06	0.00
	300				9	0										
	150				7	0										
	200			±3	8	0	60	1	5	15						
	300				9	0	00	1	5				5			0.15
SE30	400	±10	±5		9	5					20	5		0.07	0.15	0.15
5250	500	<u> </u>	<u> </u>		1(00	100			25		5		_		
	600				1.	10	100	2	5	25						
	700			_	12	20		2	0	_			_			_
	750				13	30										
	340				9	5	60	3	5	35						
	440				1(00	00	0	0	55						
	540				1.	10	100									
SE45	640	±10	±5	±3	12	20	100	4	0	40	20	5	5	0.1	0.2	0.2
	740				13	30	120									
	840				15	50	150	5	0	50						
	940				17	70	150	5	0	50						

(Note 1) Measurement is to be performed with KURODA's specified motor mounted.

(Note 2) Above starting torque value is applied when the standard grease is used. The value may change depending on the properties of the grease.



INERTIA

	Guide rail		Without dus	tproof cover	•		With dustp	roof cover	
		Long	block	Short	block	Long	block		t block
Model No	length	1 block	2 blocks	1 block	2 blocks	1 block	2 blocks	1 block	2 block
	(mm)	A	В	С	D	A	В	С	D
	100	0.0111	_			0.012	_		
SE1501	150	0.0160	0.0161	-	_	0.0161	0.0162	-	_
	200	0.0210	0.0211			0.0211	0.0212		
	100	0.0115	_			0.0116	_		
SE1502	150	0.0164	0.0167	-	_	0.0166	0.0171	-	_
	200	0.0214	0.0217			0.0216	0.0220		
	150	0.0607	—			0.0615	—		
SE2302	200	0.0764	0.0779	-	_	0.0772	0.0787		_
OLLOOL	250	0.0921	0.0936			0.0929	0.0944		
	300	0.1080	0.1090			0.1090	0.1100		
	150	0.0696				0.0741	_		
SE2305	200	0.0853	0.0946	-	_	0.0898	0.0992	-	_
022000	250	0.1010	0.1100			0.1060	0.1150		
	300	0.1170	0.1260			0.1210	0.1310		
	150	0.157	—			0.162	_		
	200	0.196	_			0.201	_		
	300	0.273	0.284			0.277	0.289		
SE3004	400	0.350	0.361	-	_	0.354	0.366	-	_
	500	0.426	0.438			0.431	0.442		
	600	0.503	0.514			0.507	0.519		
	700	0.580	0.591			0.584	0.596		
	150	0.165	_			0.172	_		
	200	0.203	_			0.21	_		
	300	0.28	0.298			0.287	0.305		
SE3005	400	0.356	0.374	-	_	0.363	0.381	-	_
	500	0.433	0.451			0.44	0.458		
	600	0.51	0.528			0.517	0.535		
	700	0.587	0.605			0.593	0.611		
	150	0.222	_			0.25	_		
	200	0.261				0.288	_		
	300	0.337	0.409			0.365	0.437		
SE3010	400	0.414	0.486	-	_	0.442	0.514		_
0_00.0	500	0.491	0.562			0.518	0.59		
	600	0.567	0.639			0.595	0.667		
	700	0.644	0.716			0.672	0.744		
	750	0.682	0.754	4.01		0.71	0.782	4.00	
	340	1.63	1.68	1.61	1.64	1.65	1.72	1.62	1.67
	440	2.01	2.10	1.99	2.03	2.03	2.11	2.01	2.06
054505	540	2.40	2.46	2.38	2.42	2.42	2.50	2.40	2.45
SE4505	640	2.79	2.85	2.77	2.81	2.81	2.89	2.78	2.83
	740	3.17	3.24	3.16	3.20	3.20	3.28	3.17	3.22
	840	3.56	3.62	3.55	3.59	3.59	3.67	3.56	3.61
	940	3.95	4.01	3.94	3.97	3.98	4.05	3.95	4.00
	340	1.81	2.04	1.73	1.88	1.89	2.20	1.78	1.98
	440	2.20	2.42	2.12	2.27	2.28	2.59	2.17	2.37
0 - 4 - 4 0	540	2.58	2.81	2.51	2.66	2.67	2.98	2.56	2.76
SE4510	640	2.97	3.20	2.90	3.05	3.06	3.37	2.95	3.15
	740	3.36	3.59	3.28	3.44	3.44	3.76	3.33	3.54
	840	3.75	3.98	3.67	3.82	3.83	4.14	3.72	3.93
	940	4.14	4.36	4.06	4.21	4.22	4.53	4.11	4.31
	340	2.54	3.45	2.23	2.84	2.87	4.12	2.43	3.24
	440	2.92	3.84	2.62	3.23	3.26	4.50	2.82	3.63
054500	540	3.31	4.22	3.01	3.62	3.65	4.89	3.21	4.02
SE4520	640	3.70	4.61	3.40	4.00	4.03	5.28	3.60	4.41
	740	4.09	5.00	3.78	4.39	4.42	5.67	3.99	4.80
	840	4.48	5.39	4.17	4.78	4.81	6.06	4.38	5.19


(Note 1) Dash (-) in the above table means the configuration is not available.



Model No.	Lead	Slide block	Guide rail length	Performance grade
	* *	*	* * *	*
SE15	01: 1mm 02: 2mm	A: With 1 long block B: With 2 long blocks	100, 150, 200	W, U, H

LONG BLOCK CONFIGURATIONS

With 1 long block: A (With 2 long blocks: B)





Motor bracket configuration	Type of cover	Sensor
* *	*	*
A0, A1, A2, A3	N: Without cover C: With dustproof cover	N: Without sensor K, E: Proximity sensor 1: For sensor rails only

	Surface treatment	Grease
	*	*
-	N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease

● LONG BLOCK DIMENSIONS

							(Unit: mm)
Guide rail length						Maximu	m stroke
	1	N_1	$M_1 \times P_1$	N_2	P ₂	Long	block
	L ₂					A: 1 block	B: 2 blocks
100	147		1×50		106	60	
150	197	25	2×50	3	156	110	70
200	247		3×50		206	160	120

PERMISSIBLE SPEED / MASS

Guide rail length	Permissible s	speed (mm/s)		Mass (kg)										
L ₁	Le	ad	Withou	t cover	With	cover	Slide block							
(mm)	1mm	2mm	А	В	А	В	Without cover	With cover						
100	133	260	0.28		0.31	_								
150	100	200	0.36	0.39	0.39	0.44	0.03	0.05						
200	90	180	0.45	0.48	0.48	0.53								

(Note 1) The mass indicated in the columns "Without cover" and "With cover" in the above table includes the mass of slide block. (Note 2) Hex socket head cap screws ($M3 \times 5$, with stainless steel) should be used for fixing guide rails.


(Note 3) For long rail configurations, please consult KURODA.



Model No.	Lead	Slide block		Guide rail length	Performance grade
	* *	*		* * *	*
SE15	01: 1mm 02: 2mm	A: With 1 long block B: With 2 long blocks]-	100, 150, 200	W, U, H

MOTOR BRACKET CONFIGURATIONS

Motor bracket configuration: A0






Motor bracket configuration	Type of cover	Sensor]
* *	*	*	
A0, A1, A2, A3	N: Without cover C: With dustproof cover	N: Without sensor K, E: Proximity sensor 1: For sensor rails only	-


Surface treatment	Grease
*	*
N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease

MOTOR BRACKET CONFIGURATIONS (INTERMEDIATE FLANGE)


Motor bracket configuration: A1 (mass: 10g)



Motor bracket configuration: A2 (mass: 10g)



Motor bracket configuration: A3 (mass: 10g)



(Note) For A1 and A3 configuration, install the intermediate flange to motor before mounting it to actuator.



Model No.	Lead	Slide block		Guide rail length	Performance grade
	* *	*		* * *	*
SE15	01: 1mm 02: 2mm	A: With 1 long block B: With 2 long blocks	_	100, 150, 200	W, U, H

MOTOR BRACKET CONFIGURATIONS AND MOTOR OPTION

		Motor optio	Motor	Recommended coupling			
Motor type	De Maker Series Model No. Outp		Output			bracket configuration	
	MITSUBISHI	MELSERVO	HC-AQ0135	10W	A2		
AC SERVO	ELECTRIC	J2-Jr	HC-AQ0235	235 20W	AZ		
motor	YASKAWA		SGMMV-A1	10W	A1	ALS-014 (MIKI PULLEY)	
	ELECTRIC	Sigma-V	SGMMV-A2	20W	AI	ALS-014 (IVIINI PULLET)	
Stepping	ORIENTAL		PK223	28mm	4.2		
motor	motor MOTOR	2-Phase	PK225	28mm	A3		

 $\boldsymbol{\cdot}$ For motors other than above-mentioned, consult KURODA.

 $\boldsymbol{\cdot}$ When selecting a rigid type of coupling for connecting a motor, consult KURODA.

• For detailed specifications of above-mentioned motors and couplings, refer to catalogs or websites provided by the makers.




Motor bracket configuration	Type of cover	Sensor
* *	*	*
	N: Without cover C: With dustproof cover	N: Without sensor K, E: Proximity sensor 1: For sensor rails only

Surface treatment	Grease
*	*
N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease


SENSOR

Symbol K (NPN) / E (PNP): Proximity sensor (Azbil)

Without cover





With dustproof cover



SENSOR RAIL

Sensor rails only available with no sensors.









Model No.	Lead	Slide block		Guide rail length	Performance grade
	* *	*		* * *	*
SE23	02: 2mm 05: 5mm	A: With 1 long block B: With 2 long blocks	-	150, 200, 250, 300	W, U, H

LONG BLOCK CONFIGURATIONS







50.5

50.5

Motor bracket configuration	Type of cover	Sensor
* *	*	*
A0, A1, A2, A3, A5, A6, A7	N: Without cover C: With dustproof cover	N: Without sensor S: Photo-microsensor K, E: Proximity sensor 1: For sensor rails only

	Surface treatment	Grease]	
	*	*		
_	N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease	_	No s PS: PR: PSR:

Dowel pin hole	
* *	
No symbol: No dowel pin h PS: For slide block only PR: For guide rail only PSR: For both slide block and guide	

● LONG BLOCK DIMENSIONS

							(Unit: mm)
Guide rail length	Overall length					Maximu	m stroke
		$N_1 = M_1 \times P_1 = N_2 = M_1$	N ₁ M ₁ ×P ₁ N ₂		$M_2 \times P_2$	Long block	
	L ₂					A: 1 block	B: 2 blocks
150	210	35	1×80	25	1×100	76	
200	260	20	2×80	50		126	57
250	310	45	2/00	25	2×100	176	107
300	360	30	3×80	50	2/100	226	157

PERMISSIBLE SPEED / MASS

Guide rail length	Permissible s	speed (mm/s)	Mass (kg)							
L ₁	Le	ad	Withou	Without cover With co		Without cover Wi		cover	Slide block	
(mm)	2mm	5mm	А	В	A	В	Without cover	With cover		
150			1.00		1.11					
200	200	490	1.21	1.35	1.32	1.46	0.14	0.00		
250	200	490	1.41	1.56	1.52	1.67	0.14	0.26		
300]		1.61	1.76	1.73	1.88				


(Note 1) The mass indicated in the columns "Without cover" and "With cover" in the above table includes the mass of slide block. (Note 2) For long rail configurations, please consult KURODA.



Model No.	Lead	Slide block		Guide rail length	Performance grade
	* *	*		* * *	*
SE23	02: 2mm 05: 5mm	A: With 1 long block B: With 2 long blocks	_	150, 200, 250, 300	W, U, H

MOTOR BRACKET CONFIGURATIONS

Motor bracket configuration: A0







Motor bracket configuration	Type of cover	Sensor		Surface treatment	Grease]	Dowel pin hole
* *	*	*		*	*		* *
A0, A1, A2, A3, A5, A6, A7	N: Without cover C: With dustproof cover	N: Without sensor S: Photo-microsensor K, E: Proximity sensor 1: For sensor rails only	-	N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease	-	No symbol: No dowel pin hole PS: For slide block only PR: For guide rail only PSR: For both slide block and guide rail

MOTOR BRACKET CONFIGURATIONS (INTERMEDIATE FLANGE)


Motor bracket configuration: A1 (mass: 28g)



Motor bracket configuration: A2 (mass: 12g)



Motor bracket configuration: A3 (mass: 24g)




(Note) For A2 configuration, install the intermediate flange to motor before mounting it to actuator.




Model No.	Lead	Slide block	Guide rail length	Performance grade
	* *	*	* * *	*
SE23	02: 2mm 05: 5mm	A: With 1 long block B: With 2 long blocks	 150, 200, 250, 300	W, U, H

MOTOR BRACKET CONFIGURATIONS (INTERMEDIATE FLANGE)


Motor bracket configuration: A5 (mass: 32g)



Motor bracket configuration: A6 (mass: 16g)



Motor bracket configuration: A7 (mass: 8g)



(Note) For A5, A6, and A7 configuration, install the intermediate flange to motor before mounting it to actuator.



Motor bracket configuration	Type of cover	Sensor
* *	*	*
A0, A1, A2, A3, A5, A6, A7	N: Without cover C: With dustproof cover	N: Without sensor S: Photo-microsensor K, E: Proximity sensor 1: For sensor rails only

	Surface treatment	Grease	
	*	*	
-	N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease	-

MOTOR BRACKET CONFIGURATIONS AND MOTOR OPTION

		Motor optio	n		Motor			
Motor type	Maker	Series	Model No.	Output	bracket configuration	Recommended coupling		
	PANASONIC				MSM5BZ21A	5W		
			MSM1AZ21A	10W	A2			
		MINAS	MSM2AZ21A	20W				
		A4	MSMD5A	50W				
			MSMD01	100W				
		MINAS	MSME5A	50W	A3			
		A5	MSME01	100W				
		MELSERVO	HF-KP(MP)053	50W				
	MITSUBISHI	JЗ	HF-KP(MP)13	100W				
	ELECTRIC	MELSERVO	HG-KR(MR)053	50W	A1			
		J4	HG-KR(MR)13	100W				
			SGMJV, SGMAV-5A	50W				
		Sigma-V	SGMJV, SGMAV-01	100W				
	YASKAWA		SGMAV-C2	150W				
	ELECTRIC		SGM7J-A5	50W	A1			
AC SERVO		Sigma-7	SGM7J-01	100W				
motor			SGM7J-C2	150W				
			Q1AA04003D	30W				
	SANYO ELECTRIC		Q1AA04005D	50W	A1	SFC-010DA2(MIKI PULLEY)		
			Q1AA04010D	100W				
			R2AA04005	50W				
			R2AA04010	100W				
	CITIZEN		EA-2565	12W	A 7	ACD-19A(ISEL)		
	CHIBA	EA	EA-2580	20W	A7			
			ADMA-R5	50W	Δ.1			
	HITACHI	AD	ADMA-01	100W	A1			
			TS4601	30W				
	TAMAGAWA	TS46	TS4602	50W	A1			
	SEIKI		TS4603	100W				
	FANUC	FANUC	EANILIO	0	βM0.2	50W	A1	
			β	βM0.3	100W	AI		
			ASC3	28mm	A6			
		a step	AS46, ASC46	□42mm	A5			
			AR4, ARL4	_42mm	AS			
	ORIENTAL		CSK52, CRK52	28mm	A6			
	MOTOR	5-Phase	CSK54, CRK54	□42mm				
Stepping motor	MOTOR	J-FIIdSe	RK54	42mm	A5			
			RKS54	□42mm				
motor		2-Phase	PK22, CSK22	28mm	A6			
		2-1 1030	PK24, CSK24, UMK24	_42mm	A5			
	SANYO ELECTRIC	5-Phase	F series⊡42mm	□42mm	A5			
	TECHNO DRIVE	5-Phase	*K-S54*	□42mm	A5			

 $\boldsymbol{\cdot}$ For motors other than above-mentioned, consult KURODA.

 $\boldsymbol{\cdot}$ When selecting a rigid type of coupling for connecting a motor, consult KURODA.

• For detailed specifications of above-mentioned motors and couplings, refer to catalogs or websites provided by the makers.




Model No.	Lead	Slide block		Guide rail length	Performance grade
	* *	*		* * *	*
SE23	02: 2mm 05: 5mm	A: With 1 long block B: With 2 long blocks	_	150, 200, 250, 300	W, U, H


SENSOR

Symbol S (NPN): Photo-microsensor (Panasonic Industrial Devices SUNX)

Without cover




Symbol K (NPN) / E (PNP): Proximity sensor (Azbil)




Without cover





With dustproof cover




SENSOR RAIL

15

Sensor rails only available with no sensors.

Sensor rail No. 1





Motor bracket configuration	Type of cover	Sensor
* *	*	*
A0 A1 A2 A3 A5 A6 A7	N: Without cover C: With dustproof cover	N: Without sensor S: Photo-microsensor K, E: Proximity sensor 1: For sensor rails only


	Surface treatment	Grease		Dowel pin hole
	*	*		* *
-	N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease	-	No symbol: No dowel pin hole PS: For slide block only PR: For guide rail only PSR: For both slide block and guide rail


• DOWEL PIN HOLE

Dowel pin holes are applicable on the slide blocks with part number "PS", sub-tables "PR"or slide blocks and sub-tables "PSR". For an acutuator with 2 blocks, they are on both driving-side block and driven-side block. Please note that dowel pins are not equipped.


Long block without dustproof cover with "PS"

Long block with dustproof cover with "PS"





Guide rail with "PR"



			(Unit: mm)
Guide rail length	Ν	М	Dowel pin height
150	35	80	
200	20	160	Less than 5.9
250	45	100	Less man 5.9
300	30	240	

Notice: In case dowel pin is stuck out from the U-guide rail, it may interfere with and break the slide block.




Model No.	Lead	Slide block	Guide rail length	Performance grade
	* *	*	* * *	*
SE30	04: 4mm 05: 5mm 10: 10mm	A: With 1 long block B: With 2 long blocks	 150, 200, 300, 400, 500, 600, 700, 750	W, U, H

LONG BLOCK CONFIGURATIONS


With 1 long block: A (With 2 long blocks: B) L_2 Lı 59 N₁ $M_1 \times P_1$ 34 10 84.4 76.8 5.2 84.4 (min.) Pı ¢6h7 30 30 Ó ÷ • ۲ • **_** \oplus 7 4-M5 depth 8 $2 \times (M_1 + 1)$ -5.5 drilled hole 30 9.5 spot facing depth 5.4 4-M3 depth 6 53.8 15 (depth of groove 1) Maximum stroke (with 1 block) (42.2) (47.4) 2-M4 depth 6 (both sides) 33.6 29.5 P₂ 52 ß $M_2 \times P_2$ N2 $2 \times (M_2 + 1)$ -M3 depth 6 (both sides)

With dustproof cover



Without cover

With dustproof cover





Motor bracket configuration	Type of cover	Sensor
* *	*	*
A0, A1, A2, A3, A4, A5, A7, B1, RN, E□, F□	N: Without cover C: With dustproof cover	N: Without sensor M, Y, C, P: Photo-microsensor K, E: Proximity sensor 1: For sensor rails only

	Surface treatment	Grease	
	*	*	
-	N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease	-

Dowel pin hole
* *
No symbol: No dowel pin hole PS: For slide block only PR: For guide rail only PSR: For both slide block and guide rail

● LONG BLOCK DIMENSIONS

							(Unit: mm)				
Guide rail length	ide rail length Overall length				Maximum stroke						
, , , , , , , , , , , , , , , , , , ,		N_1	$M_1 \times P_1$	N ₂	$M_2 \times P_2$	Long	block				
L ₁	L ₂										A: 1 block
150	217	25	1×100 2×100	25	1×100	60	—				
200	267	50			1/100	110	—				
300	367				2×100	210	126				
400	467		3×100	50	3×100	310	226				
500	567		4×100		4×100	410	326				
600	667		5×100		5×100	510	426				
700	767		6×100		6×100	610	526				
750	817	25	7×100	25	7×100	660	576				

PERMISSIBLE SPEED / MASS

Guide rail length	Permissible speed (mm/s) Lead			Mass (kg)							
L ₁				Without cover		With cover		Slide block			
(mm)	4mm	5mm	10mm	А	В	А	В	Without cover	With cover		
150				1.6		1.7	_		0.40		
200	320			1.9		2.1	_				
300		320 400	810	2.6	2.9	2.7	3.2				
400				3.3	3.6	3.4	3.8	0.30			
500				3.9	4.2	4.1	4.5	0.30			
600	240	300	600	4.6	4.9	4.7	5.1				
700	170	210	430	5.2	5.5	5.4	5.8				
750		—	380	5.6	5.9	5.7	6.1				

(Note 1) Guide rail length of 750 mm is available only for SE3010.


(Note 2) The mass indicated in the columns "Without cover" and "With cover" in the above table includes the mass of slide block. (Note 3) For long rail configurations, please consult KURODA.




Model No.	Model No. Lead		Slide block		Performance grade	
	* *	*		* * *	*	
SE30	04: 4mm 05: 5mm 10: 10mm	A: With 1 long block B: With 2 long blocks]-	150, 200, 300, 400, 500, 600, 700, 750	W, U, H	

MOTOR BRACKET CONFIGURATIONS

Motor bracket configuration: A0



Motor bracket configuration: RN




Mass of the RN configuration is 0.085 kg less than the value shown in the table on page 71.



Motor bracket configuration	Type of cover	Sensor		Surface treatment	Grease		Dowel pin hole
* *	*	*		*	*		* *
A0, A1, A2, A3, A4, A5, A7, B1, RN, E□, F□	N: Without cover C: With dustproof cover	N: Without sensor M, Y, C, P: Photo-microsensor K, E: Proximity sensor 1: For sensor rails only	-	N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease	-	No symbol: No dowel pin hole PS: For slide block only PR: For guide rail only PSR: For both slide block and guide rail


MOTOR BRACKET CONFIGURATIONS (INTERMEDIATE FLANGE)

Motor bracket configuration: A1 (mass: 25g)




Motor bracket configuration: A2 (mass: 25g)


Motor bracket configuration: A3 (mass: 55g)




Motor bracket configuration: A4 (mass: 71g)




Motor bracket configuration: A5 (mass: 46g)







Motor bracket configuration: A7 (mass: 64g)



Motor bracket configuration: B1 (mass: 37g)



4-3.4 drilled hole 6 spot facing depth 3.5 (from back side)



(Note) For B1 configuration, install the intermediate flange to motor before mounting it to actuator.

SE series



Model No.	Lead	Slide block		Guide rail length	Performance grade
	* *	*]	* * *	*
SE30	04: 4mm 05: 5mm 10: 10mm	A: With 1 long block B: With 2 long blocks	1-	150, 200, 300, 400, 500, 600, 700, 750	W, U, H

MOTOR BRACKET CONFIGURATIONS AND MOTOR OPTION

		Motor optio	n		Motor	
Motor type	Maker	Series	Model No.	Output	bracket configuration	Recommended coupling
		MINAS	MSMD5A	50W		
DANASC	PANASONIC	A4	MSMD01	100W	A2	SFC-020DA2 (MIKI PULLEY)
	FANASONIC	MINAS	MSME5A	50W	, , , , , , , , , , , , , , , , , , , ,	ACD-27A (ISEL)
		A5	MSME01	100W		
		MELSERVO	HF-KP(MP)053	50W	A1	SFC-020DA2 (MIKI PULLEY)
		J3	HF-KP(MP)13	100W		ACD-27A (ISEL)
	MITSUBISHI		HF-KP(MP)23	200W	A7	XBW-27C2 (NABEYA BI-TECH)
	ELECTRIC	MELSERVO	HG-KR(MR)053	50W	A1	SFC-020DA2(MIKI PULLEY)
		J4	HG-KR(MR)13	100W		ACD-27A (ISEL)
		_	HG-KR(MR)23	200W	A7	XBW-27C2 (NABEYA BI-TECH)
			SGMJV, SGMAV-5A	50W		SFC-020DA2 (MIKI PULLEY)
		Sigma-V	SGMJV, SGMAV-01	100W	A1	ACD-27A (ISEL)
			SGMAV-C2	150W	A 7	
	YASKAWA		SGMJV, SGMAV-02	200W	A7	XBW-27C2 (NABEYA BI-TECH)
	ELECTRIC		SGM7J-A5	50W		SFC-020DA2 (MIKI PULLEY)
		Sigma-7	SGM7J-01	100W	A1	ACD-27A (ISEL)
			SGM7J-C2	150W	A 7	
AC SERVO			SGM7J-02	200W	A7	XBW-27C2 (NABEYA BI-TECH)
motor		SANMOTION	Q1AA04003D	30W 50W	A1	SFC-020DA2 (MIKI PULLEY)
			Q1AA04005D		AI	ACD-27A (ISEL)
	SANYO		Q1AA04010D	100W		
	ELECTRIC		Q1AA06020D	200W	A7	XBW-27C2 (NABEYA BI-TECH) SFC-020DA2 (MIKI PULLEY)
		SANMOTION	R2AA04005 R2AA04010	50W 100W	A3	
		R				ACD-27A (ISEL)
			R2AA06020	200W	A7	XBW-27C2(NABEYA BI-TECH)
	HITACHI	AD	ADMA-R5 ADMA-01	50W 100W	A1	
			TS4601	30W		SFC-020DA2 (MIKI PULLEY)
	TAMAGAWA		TS4602	50W	A1	ACD-27A (ISEL)
	SEIKI	TS46	TS4602 TS4603	100W	AI	
	SEIN		TSM3202	200W	A7	XBW-27C2(NABEYA BI-TECH)
			β M0.2	50W		SFC-020DA2 (MIKI PULLEY)
	FANUC	β	β M0.3	100W	A1	ACD-27A (ISEL)
			R88M-K05030	50W		SFC-020DA2 (MIKI PULLEY)
	OMRON	G5	R88M-K10030	100W	A1	ACD-27A (ISEL)
	OWITON	us	R88M-K20030	200W	A7	XBW-27C2(NABEYA BI-TECH)
			AS46, ASC46	42mm		
		a step	AR4, ARL4	42mm	-	
	ORIENTAL MOTOR		CSK54, CRK54	42mm	B1	SFC-010DA2(MIKI PULLEY)
		5-Phase	RK54, RKS54	42mm		ACD-19A(ISEL)
			PK24, CSK24, UMK24	42mm		
		2-Phase				SFC-020D2 (MIKI PULLEY)
_		2111000	PK26, CSK26, UMK26	□60mm	A5	ACD-27A (ISEL)
Stepping						SFC-010DA2(MIKI PULLEY)
motor	motor SANYO		F series 42mm	□42mm	B1	ACD-19A (ISEL)
	ELECTRIC	5-Phase				SFC-020DA2 (MIKI PULLEY)
			F series⊡60mm	□60mm	A4	ACD-27A (ISEL)
						SFC-010DA2(MIKI PULLEY)
	TECHNO		*K-S54*	□42mm	B1	ACD-19A (ISEL)
	DRIVE	5-Phase				SFC-020DA2 (MIKI PULLEY)
			K-S(M)56	□60mm	A4	ACD-27A (ISEL)
	1	1	I		1	

• For motors other than above-mentioned, consult KURODA.

• When selecting a rigid type of coupling for connecting a motor, consult KURODA.


· For detailed specifications of above-mentioned motors and couplings, refer to catalogs or websites provided by the makers.





Motor bracket configuration	Type of cover	Sensor	Surface treatment	Grease]	Dowel pin hole
* *	*	*	*	*		* *
A0, A1, A2, A3, A4, A5, A7, B1, RN, E□, F□	N: Without cover C: With dustproof cover	N: Without sensor M, Y, C, P: Photo-microsensor K, E: Proximity sensor 1: For sensor rails only	 N: Standard treatment L: Anti corrosive black coating 	N: Standard grease S: Dust preventive grease	-	No symbol: No dowel pin hole PS: For slide block only PR: For guide rail only PSR: For both slide block and guide rail

PARALLEL MOTOR MOUNTING



Motor position No. Pulley Inner dia. Mark Applicable motor EΠ Inner dia. ϕ 8 Panasonic 50 - 100W motor and so on Yaskawa 50 - 100W motor and so on

Sanyo Electric

Check the spec. if the motor can be assembled before using.

(th

42

42.3

21

Motor position No. "3"

8

0.3

Mitsubishi Electric 50 - 100W motor and so on

50 - 100W motor and so on

Motor position No. "6"

- · Pulley unit position can be adjusted at every 90 degree. · Motor parallel mounting can be equipped with dustproof
- cover and sensor.
- Fill Motor position No. in .
- If the pulley cover may not be removable due to restrictions arising from direction of the unit, consult KURODA for modifying positions of the pulley-cover fixing bolts (3 M3 hex socket bolts).
- · Tension plate position can be built in pulley cover.
- · Although tension plate is attached inside the cover with standard specifications, it can also be attached to outside the cover. Consult KURODA for such modification.


17771 JENATEC

F


Inner dia. ϕ 8

Fullfill the motor position No. in \Box .

- The mass is 0.2kg larger than the values shown in table on page 71.
- Inertia moment is 2.22×10⁻⁶kg• m² larger than the value shown in table on page 55.



Parallel motor mounting type F Tension plate dimension




75

Model No.	Lead	Slide block		Guide rail length	Performance grade
	* *	*		* * *	*
SE30	04: 4mm 05: 5mm 10: 10mm	A: With 1 long block B: With 2 long blocks	_	150, 200, 300, 400, 500, 600, 700, 750	W, U, H

SENSOR


Symbol C (NPN) / P (PNP), M / Y (PNP): Photo-microsensor (OMRON, Panasonic Industrial Devices SUNX)

Without dustproof cover



Symbol K (NPN) / E (PNP): Proximity sensor (Azbil)


Without dustproof cover



With dustproof cover

With dustproof cover


20



SENSOR RAIL

Sensor rails only available with no sensors.

Sensor rail No. 1





Motor bracket configuration	Type of cover	Sensor
* *	*	*
A0, A1, A2, A3, A4, A5, A7, B1, RN, E□, F□	N: Without cover C: With dustproof cover	N: Without sensor M, Y, C, P: Photo-microsensor K, E: Proximity sensor 1: For sensor rails only

Surface treatment	Grease]	Do
*	*		
 N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease	-	No symbol PS: For sli PR: For gu PSR: For both


	Dowel pin hole
	* *
-	No symbol: No dowel pin hole PS: For slide block only PR: For guide rail only PSR: For both slide block and guide rail

DOWEL PIN HOLE


Dowel pin holes are applicable on the slide blocks with part number "PS", sub-tables "PR"or slide blocks and sub-tables "PSR". For actuators with 2 blocks, they are on both driving-side block and driven-side block. Please note that dowel pins are not equipped.


Long block without dustproof cover with "PS"

Long block with dustproof cover with "PS"



Guide rail with "PR"





			(Unit: mm)
Guide rail length	Ν	М	Dowel pin height
150	25	100	
200		100	
300		200	
400	50	300	Less than 8
500	50	400	Less than o
600		500	
700		600	
750	25	700	

Notice: In case dowel pin is stuck out from the U-guide rail, it may interfere with and break the slide block.





Model No.	Lead	Slide block		Guide rail length	Performance grade
	* *	*		* * *	*
SE45	05: 5mm	A: With 1 long block	7-	340, 440, 540, 640, 740, 840,	
	10: 10mm 20: 20mm	B: With 2 long blocks C: With 1 short block D: With 2 short blocks		940	W, U, H

LONG BLOCK CONFIGURATIONS

With 1 long block: A (With 2 long blocks: B) L2 13 L1 77 $M_1 \times P_1$ N₁ 51 P1 115 6 109 18 80 φ10 h7 1<u>1</u>5 (min.) 46 • · (h) ₽₽ • ¢ é∰) 46 $2 \times (M_1 + 1)$ -6.6 drilled hole 4-M6 depth 12 8- ø 2.5 depth 6 11 spot facing depth 6.5 (sensor dog mounting hole) (57.5) Maximum stroke (with 1 block) (63.5) 49.5 2-M4 depth 6 (both sides) 1.5 4 15 7.5 53 P₂ $M_2 \times P_2$ N2 $2 \times (M_2 + 1)$ -M3 depth 6 (both sides) (sensor rail mounting hole) With dustproof cover 80 115 (min.) -00 -@-一 8 盟 -@ \$ - + + + -661 4-M6 depth 12 30 4-M5 depth 10 46

Without cover







44

Motor bracket configuration	Type of cover	Sensor
* *	*	*
A0, A1, A2, A3, A4, A5, A6, RN, E□, F□, G□	N: Without cover C: With dustproof cover	N: Without sensor M, Y, C, P: Photo-microsensor K, E: Proximity sensor 1: For sensor rails only

	Surface treatment	Grease		
	*	*		
_	N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease	_	

	Dowel pin hole
	* *
PR: For	bol: No dowel pin hole slide block only guide rail only both slide block and guide rail

● LONG BLOCK DIMENSIONS

							(Unit: mm)
Guide rail length	Overall length					Maximu	m stroke
	, Ŭ	N_1	$M_1 \times P_1$	N ₂	$M_2 \times P_2$	Long	block
L ₁	L ₂					A: 1 block	B: 2 blocks
340	430	_	2×100		1×300	219	104
440	530		3×100		1×400	319	204
540	630		4×100		2×250	419	304
640	730	70	5×100	20	2×300	519	404
740	830		6×100		2×350	619	504
840	930		7×100		2×400	719	604
940	1030		8×100		3×300	819	704


PERMISSIBLE SPEED / MASS

Guide rail length	Permis	sible speed	(mm/s)			Mass	s (kg)		
L1		Lead		Withou	it cover	With	cover	Slide	block
(mm)	5mm	10mm	20mm	А	В	А	В	Without cover	With cover
340				6	6.9	6.9	8.1		
440				7.3	8.2	8.3	9.5		
540	260	520	520 1040	8.5	9.4	9.6	10.9		
640	200	520		9.8	10.7	11	12.2	0.86	1.19
740				11	11.9	12.4	13.6		
840				12.3	13.2	13.8	15		
940	200	410	830	13.5	14.4	15.1	16.4		

(Note 1) The mass indicated in the columns "Without cover" and "With cover" in the above table includes the mass of slide block. (Note 2) For long rail configurations, please consult KURODA.

Model No.	Lead	Slide block	Guide rail length	Performance grade
	* *	*	* * *	*
SE45	05: 5mm	A: With 1 long block	 040 440 540 640 740 840	
	10: 10mm 20: 20mm	B: With 2 long blocks C: With 1 short block D: With 2 short blocks	340, 440, 540, 640, 740, 840, 940	W, U, H

SHORT BLOCK CONFIGURATIONS



KURODA

V//// JENATEC

Motor bracket configuration	Type of cover	Sensor
* *	*	*
A0, A1, A2, A3, A4, A5, A6, RN, E□, F□, G□	N: Without cover C: With dustproof cover	N: Without sensor M, Y, C, P: Photo-microsensor K, E: Proximity sensor 1: For sensor rails only

	Surface treatment	Grease		Ē
	*	*		
_	N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease	-	

Dowel pin hole					
* *					
No symbol: No dowel pin hole PS: For slide block only PR: For guide rail only PSR: For both slide block and guide rail					

SHORT BLOCK DIMENSIONS

							(Unit: mm)
Guido rail longth	Overall length					Maximu	m stroke
Guide rail length	Overall length	N_1	$M_1 \times P_1$	N_2	$M_2 \times P_2$	Short	block
L ₁	L ₂					C: 1 block	D: 2 blocks
340	430	_	2×100		1×300	249	164
440	530		3×100		1×400	349	264
540	630		4×100		2×250	449	364
640	730	70	5×100	20	2×300	549	464
740	830		6×100		2×350	649	564
840	930		7×100		2×400	749	664
940	1030		8×100		3×300	849	764

PERMISSIBLE SPEED / MASS

Guide rail length	Permis	sible speed	(mm/s)			Mass	s (kg)		
L1		Lead		Withou	it cover	With	cover	Slide	block
(mm)	5mm	10mm	20mm	С	D	С	D	Without cover	With cover
340				5.7	6.3	6.5	7.2		
440				7	7.6	7.8	8.6		
540	260	520	1040	8.2	8.8	9.2	10		
640	200	520	1040	9.5	10.1	10.6	11.4	0.58	0.79
740				10.7	11.3	12	12.8		
840				12	12.6	13.3	14.1		
940	200	410	830	13.2	13.8	14.7	15.5		


(Note 1) The mass indicated in the columns "Without cover" and "With cover" in the above table includes the mass of slide block. (Note 2) For long rail configurations, please consult KURODA.




Model No.	Lead	Slide block		Guide rail length	Performance grade
	* *	*		* * *	*
SE45	05: 5mm 10: 10mm 20: 20mm	A: With 1 long block B: With 2 long blocks C: With 1 short block D: With 2 short blocks	1-	340, 440, 540, 640, 740, 840, 940	W, U, H

MOTOR BRACKET CONFIGURATIONS

Motor bracket configuration: A0



Motor bracket configuration: RN



Mass of the RN configuration is 0.26 kg less than the values shown in the tables on pages 79 and 81.




Motor bracket configuration	Type of cover	Sensor
* *	*	*
A0, A1, A2, A3, A4, A5, A6, RN, E□, F□, G□	N: Without cover C: With dustproof cover	N: Without sensor M, Y, C, P: Photo-microsensor K, E: Proximity sensor 1: For sensor rails only

	Surface treatment	Grease		Γ
	*	*		
-	N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease	-	


MOTOR BRACKET CONFIGURATIONS (INTERMEDIATE FLANGE)

V//// JENATEC


Motor bracket configuration: A1 (mass: 53g)




Motor bracket configuration: A2 (mass: 53g)




Motor bracket configuration: A3 (mass: 103g)




Motor bracket configuration: A4 (mass: 73g)



Motor bracket configuration: A5 (mass: 73g)



Motor bracket configuration: A6 (mass: 64g)



Model No.	Lead	Slide block		Guide rail length	Performance grade
	* *	*		* * *	*
SE45	05: 5mm 10: 10mm 20: 20mm	A: With 1 long block B: With 2 long blocks C: With 1 short block D: With 2 short blocks	-	340, 440, 540, 640, 740, 840, 940	W, U, H

MOTOR BRACKET CONFIGURATIONS AND MOTOR OPTION

	1	Motor optio	n		Motor	Decommonded ocupling
Motor type	Maker	Series	Model No.	Output	bracket configuration	Recommended coupling
		MINAS E	MUMA02	200W	A2	SFC-030DA2 (MIKI PULLE)
			MUMA04	400W	A2	ACD-34A (ISEL)
			MSMD5A	50W	A5	SFC-020DA2(MIKI PULLE)
			MSMD01	100W	7.0	ACD-27A (ISEL)
		MINAS	MSMD02	200W	A2	SFC-030DA2(MIKI PULLE)
		A4	MSMD04	400W		ACD-34A (ISEL)
	PANASONIC		MSMD08	750W	A3	SFC-040DA2(MIKI PULLE) ACD-44A(ISEL)
			MSME5A	50W	A5	SFC-020DA2 (MIKI PULLE)
			MSME01	100W	7.0	ACD-27A (ISEL)
		MINAS	MSME02	200W	A2	SFC-030DA2(MIKI PULLE)
		A5	MSME04	400W		ACD-34A (ISEL)
			MSME08	750W	A3	SFC-040DA2 (MIKI PULLE) ACD-44A (ISEL)
			HF-KP(MP)053	50W	A4	SFC-020DA2 (MIKI PULLE)
		MELSERVO	HF-KP(MP)13	100W		ACD-27A (ISEL)
		J3	HF-KP(MP)23	200W	A1	SFC-030DA2(MIKI PULLE)
	MITSUBISHI		HF-KP(MP)43	400W	,,,,	ACD-34A (ISEL)
	ELECTRIC		HG-KR(MR)053	50W	A4	SFC-020DA2 (MIKI PULLE)
		MELSERVO	HG-KR(MR)13	100W		ACD-27A (ISEL)
		J4	HG-KR(MR)23	200W	A1	SFC-030DA2(MIKI PULLE)
			HG-KR(MR)43	400W 50W		ACD-34A (ISEL)
			SGMJV, SGMAV-5A SGMJV, SGMAV-01	100W	A4	SFC-020DA2(MIKI PULLE)
			SGMAV-C2	150W	A4	ACD-27A (ISEL)
	YASKAWA ELECTRIC	Sigma-V	SGMJV, SGMAV-02	200W	A1	
			SGMJV, SGMAV-02	400W		SFC-030DA2(MIKI PULLE
AC SERVO			SGMJV, SGMAV-04	550W		ACD-34A (ISEL)
motor			SGM7J-A5	50W	A4	
			SGM7J-01	100W		SFC-020DA2 (MIKI PULLE
			SGM7J-C2	150W		ACD-27A (ISEL)
		Sigma-7	SGM7J-02	200W		
			SGM7J-04	400W	A1	SFC-030DA2(MIKI PULLE
			SGM7J-06	550W		ACD-34A (ISEL)
			Q1AA04003D	30W		SFC-020DA2 (MIKI PULLE
		SANMOTION	Q1AA04005D	50W	A4	
			Q1AA04010D	100W]	ACD-27A(ISEL)
	SANYO	Q	Q1AA06020D	200W	A1	SFC-030DA2(MIKI PULLE
	ELECTRIC		Q1AA06040D	400W	AI	ACD-34A (ISEL)
	LLLOTTIO		R2AA04005	50W	A4	SFC-020DA2 (MIKI PULLE
		SANMOTION	R2AA04010	100W		ACD-27A (ISEL)
		R	R2AA06020	200W	A1	SFC-030DA2(MIKI PULLE
			R2AA06040	400W		ACD-34A (ISEL)
			ADMA-R5	50W	A4	SFC-020DA2(MIKI PULLE
	HITACHI	AD	ADMA-01	100W		ACD-27A (ISEL)
			ADMA-02	200W 400W	A1	SFC-030DA2 (MIKI PULLE ACD-34A (ISEL)
			ADMA-04 TS4601	30W		ACD-34A (ISEL)
			TS4602	50W	A4	SFC-020DA2(MIKI PULLE
	TAMAGAWA		TS4603	100W		ACD-27A (ISEL)
	SEIKI	TS46	TS4606	100W		
	OLIN		TS4607	200W	A1	SFC-030DA2 (MIKI PULLE
			TS4609	400W		ACD-34A(ISEL)
			β M0.2	50W		SFC-020DA2 (MIKI PULLE
	FANUC	β	β M0.2	100W	A4	ACD-27A (ISEL)
	ORIENTAL MOTOR	a step	AR6, ARL6	□60mm	A6	
Stepping	SANYO	5-Phase	F series 60mm	□60mm	A6	SFC-020DA2(MIKI PULLE
motor	ELECIKIC					ACD-27A (ISEL)


For motors other than above-mentioned, consult KURODA.
When selecting a rigid type of coupling for connecting a motor, consult KURODA.
For detailed specifications of above-mentioned motors and couplings, refer to catalogs or websites provided by the makers.



Motor bracket configuration	Type of cover	Sensor	
* *	*	*	
A0, A1, A2, A3, A4, A5, A6, RN, E□, F□, G□	N: Without cover C: With dustproof cover	N: Without sensor M, Y, C, P: Photo-microsensor K, E: Proximity sensor 1: For sensor rails only	

	Surface treatment	Grease]	Dowel pin hole
	*	*		* *
-	N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease	_	No symbol: No dowel pin hole PS: For slide block only PR: For guide rail only PSR: For both slide block and guide rail

PARALLEL MOTOR MOUNTING



Mark

Ε□

F

G

Pulley Inner dia.

Inner dia. ϕ 11

Inner dia. ϕ 14

Inner dia. $\phi 8$

Fullfill the motor position No. in \Box .

Panasonic

Yaskawa

Check the spec. if the motor can be assembled before using.

Sanyo Electric


Oriental Motor

- Pulley unit position can be adjusted at every 90 degree.
- Fill motor position No. in \Box .


If the pulley cover may not be removable due to restrictions arising from direction of the unit, consult KURODA for modifying positions of the pulley-cover fixing bolts (3 M3 cross recessed flat head machine screws).

- Motor parallel mounting can be equipped with dustproof cover and sensor.
- Although tension plate is attached inside the cover with standard specifications, it can also be attached to outside the cover. Consult KURODA for such modification.
- Tension plate position can be built in pulley cover.
- The mass is 0.7kg larger than the values shown in tables on pages 79 and 81.
- Inertia moment is 1.24×10^{-5} kg•m² larger than the value shown in table on page 55.

Parallel motor mounting type E



Parallel motor mounting type F



Parallel motor mounting type G

Applicable motor


Mitsubishi Electric 200W motor and so on

Stepping Motor 260 series and so on"

200W motor and so on

200W motor and so on

200W motor and so on




Model No.	Lead	Slide block		Guide rail length	Performance grade
	* *	*		* * *	*
SE45	05: 5mm 10: 10mm 20: 20mm	A: With 1 long block B: With 2 long blocks C: With 1 short block D: With 2 short blocks	-	340, 440, 540, 640, 740, 840, 940	W, U, H


SENSOR

Symbol C (NPN) / P (PNP), M (NPN) / Y (PNP): Photo-microsensor (OMRON, Panasonic Industrial Devices SUNX)

Without dustproof cover




With dustproof cover



Symbol K (NPN) / E (PNP): Proximity sensor (Azbil)

Without dustproof cover


With dustproof cover



SENSOR RAIL

Sensor rails only available with no sensors.

Sensor rail No. 1





Motor bracket configuration	Type of cover	Sensor
* *	* *	
A0, A1, A2, A3, A4, A5, A6, RN, E□, F□, G□	N: Without cover C: With dustproof cover	N: Without sensor M, Y, C, P: Photo-microsensor K, E: Proximity sensor 1: For sensor rails only

	Surface treatment	Grease]	
	*	*		
-	N: Standard treatment L: Anti corrosive black coating	N: Standard grease S: Dust preventive grease	-	

	Dowel pin hole		
	* *		
-	No symbol: No dowel pin hole PS: For slide block only PR: For guide rail only PSR: For both slide block and guide rail		


• DOWEL PIN HOLE

Dowel pin holes are applicable on the slide blocks with part number "PS", sub-tables "PR"or slide blocks and sub-tables "PSR". For an actuator with 2 blocks, they are on both driving-side block and driven-side block. Please note that dowel pins are not equipped.

Long block without dustproof cover with "PS"


Long block with dustproof cover with "PS"

For actuators with 2 blocks, the holes are on both blocks.




Short block without dustproof cover with "PS"


For actuators with 2 blocks, the holes are on both blocks.




Guide rail with "PR"



Short block with dustproof cover with "PS"





Notice: In case dowel pin is stuck out from the U-guide rail, it may interfere with and break the slide block.



CONTENTS


TECHNICAL DATA FOR BALLSCREW ACTUATORS

Ballscrew actuator selection guide
Expected-life design for guide
Expected-life design for ball screw and fixed side bearing
Example of selection $\textcircled{1}$ For horizontal use $\fbox{115}$
Example of selection ② For vertical use
Ballscrew actuator specification data sheet - Sample
Ballscrew actuator specification data sheet



BALLSCREW ACTUATOR SELECTION GUIDE

Similar to ball screw selections, there is no instant way of selecting appropriate ballscrew actuators for various purposes. The following is an example of general procedures in actuator selection, with some considerations to be made on each step and pages to refer to.





LIFE EXPECTANCY

The shortest life expectancy of among guid-rail, ballscrew and support bearing can be defined as the life expectancy of ballscrew actuators, SE, SG, and SC series.

The following formula is used to calculate the life expectancy.

LIFE EXPECTANCY OF GUIDE

Calculate the life expectancy of guide using the following formula:

$$L_{\rm G} = \left(\frac{f_{\rm C}}{f_{\rm W}} \cdot \frac{C}{P_{\rm T}}\right)^3 \cdot 50 - {\rm Formula} (1)$$

- L_G: Life expectancy operational length (km)
- fc : Contact factor (see Table 1)
- fw : Load factor (see Table 2)
- C : Basic dynamic load rating (N)
- P_{T} : Calculated load per block (N)

Table 1Contact factor (fc)

Number of blocks to be used in contact, when single axis module is used.	Contact factor (f _c)	
1	1.0	
2	0.81	

Table 2 Load factor (fw)

Operating	Load factor		
Vibration and shock	Speed	(f_w)	
Zero	250mm/s or less	1.0~1.5	
Small	1000mm/s or less	1.0~2.0	
Large	1000mm/s or more	2.0~3.5	

Calculation of PT

To calculate the life expectancy using Formula (1), you need to obtain the calculated load per block (P_T) in consideration of actual moment load.

If the acceleration is high or short-stroke operation is conducted, calculate P_{τ} in consideration of acceleration. This acceleration calculation is made for a mass loaded on SG, SE, and SC.

Obtain the calculated load in uniform motion, accelerated motion, and decelerated motion, and its average figure is used as P_{τ} .

For the calculation of P_{τ} , select a calculation formula according to the installation conditions.

If acceleration needs not to be considered,

 $P_T = P_{TC}$ (See Formula (2), (5) and (8)) can be used for calculation. However, you can calculate only the approximate value in this formula, therefore it is recommended that you calculate the life expectancy with an ample margin.

	Ep(E2p)	Ey(E2p)	Er(E2r)	
SG20**A	2.25×10 ⁻¹	1.89×10 ⁻¹	7.84×10 ⁻²	
SG20**B	3.98×10 ⁻²	3.34×10 ⁻²	3.92×10 ⁻²	
SG26**A	1.51×10 ⁻¹	1.27×10 ⁻¹	5.88×10 ⁻²	
SG26**B	2.72×10 ⁻²	2.28×10 ⁻²	2.94×10 ⁻²	
SG33**A	1.26×10 ⁻¹	1.06×10 ⁻¹	4.55×10 ⁻²	
SG33**B	2.20×10 ⁻²	1.84×10 ⁻²	2.27×10 ⁻²	
SG33**C	2.31×10 ⁻¹	1.94×10 ⁻¹	4.55×10 ⁻²	
SG33**D	3.09×10 ⁻²	2.59×10 ⁻²	2.27×10 ⁻²	
SG46**A	8.39×10 ⁻²	7.04×10 ⁻²	3.17×10 ⁻²	
SG46**B	1.56×10 ⁻²	1.31×10 ⁻²	1.59×10 ⁻²	
SG46**C	1.39×10 ⁻¹	1.17×10 ⁻¹	3.17×10 ⁻²	
SG46**D	2.15×10 ⁻²	1.18×10 ⁻²	1.59×10 ⁻²	
SG55**A	6.80×10 ⁻²	5.71×10 ⁻²	2.74×10 ⁻²	
SG55**B	1.35×10 ⁻²	1.14×10 ⁻²	1.37×10 ⁻²	
SE15**A	2.70×10 ⁻¹	2.45×10 ⁻¹	9.64×10 ⁻²	
SE15**B	4.50×10 ⁻²	3.80×10 ⁻²	4.82×10 ⁻²	
SE23**A	1.52×10 ⁻¹	1.37×10 ⁻¹	5.22×10 ⁻²	
SE23**B	2.54×10 ⁻²	2.29×10 ⁻²	2.61×10 ⁻²	
SE30**A	1.17×10 ⁻¹	9.83×10 ⁻²	4.54×10 ⁻²	
SE30**B	1.95×10 ⁻²	1.64×10 ⁻²	2.27×10 ⁻²	
SE45**A	8.39×10 ⁻²	7.04×10 ⁻²	3.17×10 ⁻²	
SE45**B	1.56×10 ⁻²	1.31×10 ⁻²	1.59×10 ⁻²	
SE45**C	1.26×10 ⁻¹	1.06×10 ⁻¹	3.17×10 ⁻²	
SE45**D	2.10×10 ⁻²	1.76×10 ⁻²	1.59×10 ⁻²	
SC23**A	1.52×10 ⁻¹	1.37×10 ⁻¹	5.22×10 ⁻²	
SC30**A	1.17×10 ⁻¹	9.83×10 ⁻²	4.54×10 ⁻²	
SC45**A	8.39×10 ⁻²	7.04×10 ⁻²	3.17×10 ⁻²	

(Note) The specifications of a model with two blocks show factors when the two blocks are used in contact.



Table 3 Moment equivalent factor

\bullet P_T in the case of Horizontal Movement (Horizontal Installation)

1 For uniform motion (P_{TC})

 $P_{TC} = \frac{1}{n} \cdot W + Ep \cdot M_{PL} + Ey \cdot M_{YL} + Er \cdot M_{TL} - Formula (2)$

2 For accelerated motion (P_{Ta})

 $P_{Ta} = \frac{1}{n} \cdot W + Ep (M_{PL} + m \cdot a_a \cdot Z) + Ey (M_{YL} + m \cdot a_a \cdot X) + Er \cdot M_{rL} - Formula (3)$


If item $(M_{PL}+m\cdot\alpha_{a}\cdot Z)$ or $(M_{YL}+m\cdot\alpha_{a}\cdot X)$ is a negative value, the value should be set to 0.

 $(\ensuremath{\underline{3}})$ For decelerated motion (P_Td)

 $P_{Td} = \frac{1}{n} \cdot W + Ep (M_{PL} + m \cdot \alpha_d \cdot Z) + Ey (M_{YL} + m \cdot \alpha_d \cdot X) + Er \cdot M_{rL} - Formula (4)$

If item $(M_{PL} + m \cdot \alpha_d \cdot Z)$ or $(M_{YL} + m \cdot \alpha_d \cdot X)$ is a negative value, the value should be set to 0.

- $P_{\mbox{\tiny TC}}$: Calculated load per block in uniform motion (N)
- $P_{\mbox{\tiny Ta}}$: Calculated load per block in accelerated motion (N)
- $P_{\mbox{\tiny Td}}$: Calculated load per block in decelerated motion (N)
- n : Number of block of SG / SE / SC
- W : Load (N)
- m : Load mass (kg)
- α_{a} : Acceleration in accelerated motion (m/sec²)
- α_{d} : Acceleration in decelerated motion (m/sec²) (with a minus sign)
- X : Distance from center of SG / SE / SC to center of gravity of loaded mass (mm)
- Y : Distance from center of SG / SE / SC to center of gravity of loaded mass (mm)
- Z : Distance from center of SG / SE / SC ballscrew to center of gravity of loaded mass (mm)



If a load is applied from a different direction other than W (m) in this figure, contact KURODA.

- $\mathsf{E}_{\scriptscriptstyle P}$: Moment equivalent factor in pitching direction (see Table 3)
- E_y : Moment equivalent factor in yawing direction (see Table 3)
- Er : Moment equivalent factor in rolling direction (see Table 3)
- $M_{\mbox{\tiny PL}}$: Load moment in pitching direction (N ${\boldsymbol \cdot}$ mm) $M_{\mbox{\tiny PL}} = W \, {\boldsymbol \cdot} \, Y$
- M_{yL} : Load moment in yawing direction (N \cdot mm) $M_{yL} = 0 \mbox{ (The load moment is zero under this usage.)}$
- M_{rL} : Load moment in rolling direction (N mm) $M_{rL} = W \cdot X$

(Note) For the moment directions, see Pages 3, 53 and 91.

● P^T in the Case of Horizontal Movement (Wall Installation)

(1) For uniform motion (P_{TC})

 $P_{TC} = \frac{1}{1 \cdot 19 \cdot n} \cdot W + Ep \cdot M_{pl} + Ey \cdot M_{yl} + Er \cdot M_{rl} - Formula (5)$

2 For accelerated motion (P $_{\mbox{\tiny Ta}}$)

.

Fechnical Data

$$P_{Ta} = \frac{I}{1.19 \cdot n} \cdot W + Ep (M_{PL} + m \cdot a_a \cdot Z) + Ey (M_{YL} + m \cdot a_a \cdot X) + Er \cdot M_{rL} - Formula (6)$$

If item $(M_{PL}+m \cdot a_a \cdot Z)$ or $(M_{YL}+m \cdot a_a \cdot X)$ is a negative value, the value should be set to 0.

(3) For decelerated motion (P_{Td})

$$P_{Td} = \frac{1}{1,19 \cdot n} \cdot W + Ep (M_{PL} + m \cdot a_d \cdot Z) + Ey (M_{YL} + m \cdot a_d \cdot X) + Er \cdot M_{rL} - Formula (7)$$

If item $(M_{PL}+m\cdot\alpha_d\cdot Z)$ or $(M_{YL}+m\cdot\alpha_d\cdot X)$ is a negative value, the value should be set to 0.

 $P_{\mbox{\tiny TC}}$: Calculated load per block in uniform motion (N)

- $P_{\mbox{\tiny Ta}}$: Calculated load per block in accelerated motion (N)
- $P_{\mbox{\tiny Td}}$: Calculated load per block in decelerated motion (N)
- n : Number of block of SG / SE / SC
- W: Load (N)
- m : Load mass (kg)
- α_{a} : Acceleration in accelerated motion (m/sec²)
- α_d : Acceleration in decelerated motion (m/sec²) (with a minus sign)
- X : Distance from center of SG / SE / SC to center of gravity of loaded mass (mm)
- Y : Distance from center of SG / SE /SC to center of gravity of loaded mass (mm)
- Z : Distance from center of SG / SE / SC ballscrew to center of gravity of loaded mass (mm)

Figure 2

If load is applied from a different direction other than W (m), contact KURODA.

- $\mathsf{E}_{\scriptscriptstyle P}$: Moment equivalent factor in pitching direction (see Table 3)
- E_y : Moment equivalent factor in yawing direction (see Table 3)
- Er : Moment equivalent factor in rolling direction (see Table 3)
- $M_{\mbox{\tiny PL}}$: Load moment in pitching direction (N*mm)
 - M_{pL} = 0 (The load moment is zero under this usage.)
- $M_{\scriptscriptstyle Y^L}$: Load moment in yawing direction (N+mm)
 - $\mathsf{M}_{\mathsf{yL}} = \mathsf{W} \, \boldsymbol{\cdot} \, \mathsf{Y}$
- $M_{\rm rL}$: Load moment in rolling direction (N+mm) $M_{\rm rL} = W \, \bullet \, Z$

(Note) For the moment directions, see Pages 3, 53 and 91.



P_T in the Case of Vertical Movement

(1) For uniform motion (P_{TC})

 $P_{TC} = Ep \cdot M_{PL} + Ey \cdot M_{YL} + Er \cdot M_{rL} - Formula (8)$

(2) For accelerated motion (P_{Ta})

 $P_{Ta} = Ep (M_{pL} + m \cdot a_a \cdot Z) + Ey (M_{yL} + m \cdot a_a \cdot X) + Er \cdot M_{rL} - Formula (9)$

If item $(M_{\rho L} + m \cdot \alpha_a \cdot Z)$ or $(M_{yL} + m \cdot \alpha_a \cdot X)$ is a negative value, the value should be set to 0.

3 For decelerated motion (P_{Td})

 $P_{Td} = Ep (M_{\rho L} + m \cdot a_d \cdot Z) + Ey (M_{yL} + m \cdot a_d \cdot X) + Er \cdot M_{rL} - Formula (10)$

If item $(M_{PL} + m \cdot \alpha_d \cdot Z)$ or $(M_{YL} + m \cdot \alpha_d \cdot X)$ is a negative value, the value should be set to 0.

PTC : Calculated load per block in uniform motion (N)

 α_a : Acceleration in accelerated motion (m/sec²)

n : Number of block of SG / SE / SC

W: Load (N)

m: Load mass (kg)


P_{Ta}: Calculated load per block in accelerated motion (N)

P_{Td}: Calculated load per block in decelerated motion (N)

 α_d : Acceleration in decelerated motion (m/sec²) (with a minus sign)

X : Distance from center of SG / SE / SC to center of gravity of loaded mass (mm)

Y : Distance from center of SG / SE / SC to center of gravity of loaded mass (mm) Z : Distance from center of SG / SE / SC ballscrew to center of gravity of loaded mass (mm)



If load is applied from a different direction other than W (m) in this figure, contact KURODA.

- E_p: Moment equivalent factor in pitching direction (see Table 3)
 - E_y : Moment equivalent factor in yawing direction (see Table 3)
 - Er: Moment equivalent factor in rolling direction (see Table 3)
 - $M_{\mbox{\tiny PL}}$: Load moment in pitching direction (N+mm) $M_{\mbox{\tiny PL}} = W \, \cdot \, Z$
 - M_{yL} : Load moment in yawing direction (N+mm) $M_{\text{rL}} = W \, \cdot \, X$
 - M_{rL} : Load moment in rolling direction (N·mm)
 - $M_{yL} = 0$ (The load moment is zero under this usage.)

(Note) For the moment directions, see Pages 3, 53 and 91.

 Using one of the above calculation formulas according to your usage, calculate average load in each motion to obtain calculated load per block (P_T).

$$P_{T} = \sqrt[3]{\frac{1}{(S1+S2+S3)}} (P_{Ta}^{3} \cdot S1 + P_{Tc}^{3} \cdot S2 + P_{Td}^{3} \cdot S3)}$$
Formula (11)
Formul



LIFE EXPECTANCIES OF BALL SCREW AND SUPPORT BEARING

The life expectancies of the ball screw and the support bearing can be calculated using the following common calculation formula shown as below. Therefore, compare the dynamic load ratings of the ball screw and the support bearing and substitute a smaller value in the formula for calculation.

$$L_{a} = \left(\frac{1}{f_{W}} \cdot \frac{C_{a} \text{ or } C_{b}}{P_{a}}\right)^{3} \cdot \emptyset - Formula (12)$$

Calculation of Pa

To calculate the life expectancy using Formula (6), calculate Pa in consideration of acceleration. Calculate the axial load in uniform, accelerated, and decelerated motions and its average figure is used as Pa.

In the Case of Horizontal Movement

① For uniform motion (P_{ac})

 $P_{ac} = m \cdot W + F + F_b \cdot n$ Formula (13)

2 For accelerated motion (P_aa)

 $P_{aa} = m \cdot W + F + f_b \cdot n + (m + m_b \cdot n) \alpha_a - Formula (14)$

- (3) For decelerated motion (P_{ad})
- $P_{ad} = m \cdot W + F + f_b \cdot n (m + m_b \cdot n) \alpha_d Formula (15)$

In the Case of Vertical Movement

- (1) For uniform motion (P_{ac})
- $P_{ac} = (m + m_b \cdot n) g + F + f_b \cdot n$ —Formula (16)
- (2) For accelerated motion (P_{aa})

 $P_{aa} = (m + m_b \cdot n) \cdot (g + \alpha_a) + F + f_b \cdot n_a - Formula (17)$

3 For decelerated motion (P_{ad})

 $P_{ad} = (m + m_b \cdot n) \cdot (g - \alpha_d) + F + f_b \cdot n_d - Formula (18)$

Using one of the above calculation formulas according to your usage, calculate an average axial load (Pa).

$$P_{a} = \sqrt[3]{\frac{1}{(S1+S2+S3)}} \left(P_{aa}^{3} \cdot S1 + P_{ac}^{3} \cdot S2 + P_{ad}^{3} \cdot S3 \right) - Formula (19)$$

Pa: Average axial load (N)

- S1 : Traveling distance in accelerated motion (mm) (see Figure 4)
- S2 : Traveling distance in uniform motion (mm) (see Figure 4)
- S3 : Traveling distance in decelerated motion (mm) (see Figure 4)
- $\mathsf{P}_{\scriptscriptstyle aa}$: Axial load in accelerated motion (N) Formulas (14), (17)
- $P_{\mbox{\tiny ac}}$: Axial load in uniform motion (N) Formulas (13), (16)
- $P_{\mbox{\tiny ad}}$: Axial load in decelerated motion (N) Formulas (15), (18)

- La : Life expectancy operational length (km)
- fw : Load factor (see Table 2)
- $C_{\mbox{\tiny a}}$: Basic dynamic load rating of ball screw (N)
- $C_{\scriptscriptstyle b}$: Basic dynamic load rating of support bearing (N)
- P_{a} : Ave. Axial load (N)
- Q : Ball screw lead (mm)

- $P_{\scriptscriptstyle ac}$: Axial load in uniform motion (N)
- $\mathsf{P}_{\scriptscriptstyle{\mathsf{a}\mathsf{a}}}$: Axial load in accelerated motion (N)
- $P_{\mbox{\tiny ad}}$: Axial load in decelerated motion (N)
- μ : Friction factor (0.006)
- W : Load on block (N)
- ${\sf F}$: External force (load) in axial direction (N)
- $f_{\scriptscriptstyle \rm b}$: Slide resistance per block (N) (see Table 4)
- n : Number of blocks of SG / SE
- m : Load mass (kg)
- $m_{\scriptscriptstyle b}$: Block mass of SG / SE (kg)
- g : Gravitational acceleration (9.8 m / sec²)
- α_{a} : Acceleration in accelerated motion (m / sec²)
- $\alpha_{\text{\tiny d}}$: Acceleration in decelerated motion (m / sec²)

Model No.	Accuracy grade		
woder No.	Н	Р	
SG20	2.3	4.9	
SG26	5.4	9.8	
SG33	4.4	10.2	
SG46	7.4	13.3	
SG55	9	16	

Table 4 Slide resistance per block (fb) (seal resistance)

(Unit: N)

(Unit: N)

Model No.	Accuracy grade			
WOUEI NO.	U/W			
SE15	2.0			
SE23, SC23	2.5			
SE30, SC30	2.5			
SE45, SC45	7.5			




EXAMPLE OF BALLSCREW ACTUATOR SELECTION

Linear motion robot - X-axis


<specifications></specifications>	
Mass of work and table: M	1
Load distribution	5
Maximum stroke: st	5
Fast-feed speed: v	5
Acceleration/deceleration time constant: t	C
Maximum motor speed	6
Orientating orientation	ŀ
Repeated positioning accuracy	-
Expected life	3

10kg See right side diagram. 550mm 500mm/s 0.2 s 6000min^{-1} Horizontal $\pm 0.01 \text{ mm}$ or less 30,000h

Load distribution diagram



Duty cycle model diagram



① Tentatively select SE4510A-740W-A1NN-NN in SE series, based on the conditions such as stroke and speed.

- ② Calculation of life expectancy
- $\textcircled{2}\mbox{-1.}$ Calculating life expectancy of guide

Considering the usage with moment being loaded, average load and life expectancy were calculated in accordance with "LIFE EXPECTANCY OF GUIDE" on page 111, and they resulted in 1,274 N and 39,030 hours, respectively. The load coefficient for the above calculation was determined to be 2, based on the conditions of use.

 $\textcircled{2}\mbox{-2.}$ Calculating expected life of ball screw and support bearings

Average axial load and life expectancy were calculated in accordance with "LIFE EXPECTANCIES OF BALL SCREW AND SUP-PORT BEARING" on page 114, and the axial load resulted in 14.9 N and expected life of both ball screw and support bearing in over a million hours. The load coefficient for the above calculation was determined to be 2, based on the conditions of use.

③ Results of the selection

The above calculation results of life expectancies confirmed that the tentatively selected model would satisfy the required specifications. Since there is no other particular specification to be further considered, the model is selected officially.

Selected model of ballscrew actuator: SE4510A-740W-A1NN-NN

If longer life expectancy than the calculated life is preferred, make re-calculation after changing specifications, such as upgrading model size or adding extra slide block.



EXAMPLE OF BALLSCREW ACTUATOR SELECTION


Lift - Z-axis

<specifications></specifications>
Mass of work and table: M
Load distribution
Maximum stroke: st
Fast-feed speed: v
Acceleration/deceleration time constant: t
Maximum motor speed
Orientating orientation
Repeated positioning accuracy
Life expectancy

Z=50 Center of load

Load distribution diagram

Duty cycle model diagram



① Tentative selection of ballscrew actuator

Tentatively select SG3310A-500H-A0NN-NN in SG series, based on the conditions such as strokes and speed.

2 Calculation of life expectancy

2-1. Calculating life expectancy of guide

Considering the usage with moment being loaded, average load and life expectancy were calculated in accordance with "LIFE EXPECTANCY OF GUIDE" on page 111, and they resulted in 805 N and 17,166 hours, respectively. The load coefficient for the above calculation was determined to be 2, based on the conditions of use.

2-2. Calculating expected life of ball screw and support bearing

Average axial load and life expectancy were calculated in accordance with "LIFE EXPECTANCIES OF BALL SCREW AND SUP-PORT BEARING "on page 114, and the axial load resulted in 60N and expected life of ball screw and support bearing in 44,202 and 353,620 house, respectively. The load coefficient for the above calculation was determined to be 2, based on the conditions of use.

3 Results of the selection

According to the above results of life expectancies, the life of the guide does not satisfy the life expectancy requirement. Since the ball screw and support bearing have satisfactory life expectancies, make re-calculation after changing the block on the guide. Leaving the guide rail length and required stroke as they are, change the model to SG3310D-500H-A0NN-NN.

4 Re-calculation of life

As in the previous step, average load and life expectancy were calculated in accordance with "LIFE EXPECTANCY OF GUIDE" on page 111, and they resulted in 198 N (load per block) and 146,740 hours, respectively.

(5) Results of the re-selection


The results of re-calculation of life expectancy of the guide confirmed that the selected model would satisfy required hours of life expectancy.



BALLSCREW ACTUATOR SPECIFICATION DATA SHEET

Company Name				Date		
Department			Contact personnel			
Adress			Tel / Fax			
Name of Equipme	nt/machine used			Location of use		
Drawing/conc	eptual drawing attached?	□Yes	pieces of pages		10	

Conditions of Use (Either unit system may be used.)



Ballscrew actuator specifications

Size	Lead		Slide block		Guide rail length		Precision grade	
Dust-preventive cover	Sensor	Type:		Qty:		Surface treatment		

Additional description / request

Г

*KURODA office	*	Contact personnel	


VIII JENATEC

BALLSCREW ACTUATOR LUBSEAL Lubrication Unit for Ballscrew Actuator SE23 SE30 SE45 SC23 SC30 SC45


LUBSEAL is a lubrication unit which supplies a proper volume of grease to a ballscrew actuator. It contacts grooves on screw shaft and ball rolling point on guide rail. It also fits into both ends of a slide block in a ballscrew actuator compactly. Suitable for semiconductor/liquid crystal manufacturing machines, machine tools and automobile production facilities.

FEATURES

- Simple, neat, and compact
- Remarkably extends maintenance period
- Clean and gently for the environment



ENDURANCE TEST




Lineup

				(Unit: mm)
Series	Model No.	Lead	Type of Slide Block	Applicable Guide Rail length (*)
	SE23	2, 5	Long Block	200-300
SE	SE30	4, 5, 10		200-750
	SE45	5, 10, 20	Long Block, Short Block	540-940
	SC23	2, 5		200-300
SC	SC30	4, 5, 10	Long Block	200-750
	SC45	5, 10, 20		540-940

* Because LUBSEAL are attached on both ends of a slide block, guide rail length is limited.







Maximum stroke and minimum stroke

							(Unit: mm			
		Lubrication unit with LUBSEAL								
Model NO.	Guide rail		Maximu		Minimum stroke *2					
	length	Long slide block Short slide block				Long slide block	Short slide block			
		E: 1 pc	F: 2 pcs	G:1pc	H: 2 pcs	E: 1pc, F: 2pcs	G: 1pc, H: 2pc			
SE23	200	120	-	-	-					
	250	170	95	-	-	75	-			
	300	220	145	-	-					
	200	104	-	-	-					
	300	204	114	-	-					
SE30	400	304	214	-	-					
3⊑30 *1	500	404	314	-	-	91	-			
	600	504	414	-	-					
	700	604	514	-	-					
	750	654	564	-	-					
	540	411	288	441	348					
	640	511	388	541	448					
SE45	740	611	488	641	548	123	93			
	840	711	588	741	648					
	940	811	688	841	748					
	200	110	-	-	-					
SC23	250	160	-	-	-	75	-			
	300	210	-	-	-					
	200	94	-	-	-					
	300	194	-	-	-					
	400	294	-	-	-					
SC30	500	394	-	-	-	91	_			
*1	600	494	-	-	-					
	700	594	_	_	_					
	750	644	_	_	_					
SC45	540	407	-	-	-					
	640	507	-	-	-					
	740	607	-	-	-	123	_			
	840	707	_	-	-					
	940	807	-	_	_					

Dash (-) in the above table means the configuration is not available.

*1 Guide rail length 750mm for SE30 or SC30 is applied only to a 10mm lead-actuator.

*2 To use the length under minimum stroke, consult KURODA.

▲ Operating Cautions

1. Operating temperature range is limited under 50 °C. For operating temperature exceeding 50 °C, consult KURODA.

2. Do not use organic solvent or kerosene.

3. In the case of anti-corrosive black coating specification, the coating film may be peeled off on the point of LUBSEAL contact.

4. Lubrication for SE series: To lubricate grooves on gide rail, pour grease for grease nipple. To lubricate screw shaft, apply grease to the shaft.

5. Lubrication for SC series: pour grease for central grease filler hole.

